



BMC

Auriga Severboard User's Manual

Table of Contents

CONTENTS

Preface	i
Chapter 1. Login Information	1
1.1 User Name and Password	1
1.2 Required Browser Settings.....	2
1.3 Default User Name and Password	2
1.4 Menu Bar	3
1.5 Quick Button and Logged-in User	4
Chapter 2. Dashboard	5
Chapter 3. Sensor	6
Chapter 4. FRU Information	9
Chapter 5 Logs & Reports	10
5.1 IPMI Event Log	11
5.2 System Log	13
5.3 Audit Log	14
5.4 Video Log	15
Chapter 6. Settings.....	16
6.1 Captured BSOD	16
6.2 External User services	17
6.2.1 LDAP/E-Directory Settings.....	17
6.2.2 Active Directory Settings	21
6.2.3 RADIUS Settings.....	25
6.3 KVM Mouse Settings	27
6.4 Log Settings	28
6.4.1 Log Settings Policy.....	28
6.4.2 Advanced Log Settings.....	29
6.5 Media Redirection Settings	31
6.5.1 General Settings.....	31
6.5.2 VMedia Instance Settings.....	33
6.5.3 Remote Session	35
6.6 Network Settings	37
6.6.1 Network IP Settings.....	37
6.6.2 Network Bond Configuration.....	39
6.6.3 Network Link	40
6.6.4 DNS Configuration.....	41
6.6.5 NC-SI Configuration	44
6.7 PAM Order Settings	46
6.8 Platform Event Filter	47
6.8.1 Event Filters	47
6.8.2 Alert Policies.....	50
6.8.3 LAN Destinations.....	52
6.9 Service	55
6.10 SMTP Settings.....	59
6.11 SSL Settings	62
6.11.1 Upload SSL Certificate.....	62
6.11.2 Generate SSL Certificate	63

6.11.3 View SSL Certificate	64
6.12 System Firewall	66
6.12.1 General Firewall Settings	66
6.12.2 System Firewall	70
6.13 User Management	72
6.14 Video Recording	76
6.14.1 Auto Video Settings	76
6.15 Web Instances	86
Chapter 7. Remote Control	87
7.1 KVM	87
7.2 SOL	91
Chapter 8. Images Redirection.....	92
8.1 Remote Image	92
Chapter 9. Power Control.....	94
Chapter 10. Maintenance Group	95
10.1 Backup Configuration	96
10.2 Firmware Image Location.....	97
10.3 Firmware Information	98
10.4 Firmware Update.....	99
10.5 Preserve Configuration	103
10.6 Restore Configuration	108
10.7 Restore Factory Default	109
10.8 System Administrator	110
Chapter 11. Sign Out	111
Chapter 12. Flash Tools	112
12.1 YAFUFlash	112
12.1.1 Installation in Windows.....	112
12.1.2 Installation in Linux	122
12.1.3 Installation in DOS.....	135
Chapter 13. VMCLI	140
13.1 Installation in Windows	140
13.2 Installation in Linux.....	143
Chapter 14. SOL	147
Chapter 15. Technical Support.....	148
Appendix	149

Document Release History

Release Date	Version	Update Content
October, 2018	1	User's Manual release to public.
March, 2019	1.1	1. BMC update 2. H/W spec update
April, 2019	1.2	H/W update
May, 2019	1.3	S/W update
January, 2020	1.4	S/W update
December, 2020	1.5	H/W update S/W update
May, 2021	1.6	S/W update. Spec update.
August, 2021	1.7	BMC update



Copyright © 2021 AIC®, Inc. All Rights Reserved.

This document contains proprietary information about AIC® products and is not to be disclosed or used except in accordance with applicable agreements.

Preface

Copyright

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photo-static, recording or otherwise, without the prior written consent of the manufacturer.

Trademarks

All products and trade names used in this document are trademarks or registered trademarks of their respective holders.

Changes

The material in this document is for information purposes only and is subject to change without notice.

Warning

1. A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.
2. Use only shielded cables to connect I/O devices to this equipment.
3. You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.


Disclaimer

AIC[®] shall not be liable for technical or editorial errors or omissions contained herein. The information provided is provided "as is" without warranty of any kind. To the extent permitted by law, neither AIC[®] or its affiliates, subcontractors or suppliers will be liable for incidental, special or consequential damages including downtime cost; lost profits; damages relating to the procurement of substitute products or services; or damages for loss of data, or software restoration. The information in this document is subject to change without notice.

Chapter 1. Login Information

1.1 User Name and Password

Initial access prompts you to enter the User Name and Password. A sample screenshot of the login screen is given below.



The screenshot shows a login form for 'MEGARAC SP-X'. It includes a green header, a light gray form area with 'Username' and 'Password' fields, a 'Remember Username' checkbox, a green 'Sign me in' button, and a blue 'I forgot my password' link.

Login page

The fields are explained as follows.

Username: Enter your username in this field.

Password: Enter your password in this field.

Remember Username: Check this option to remember your credentials.

Sign me in: After entering the required credentials, click the [Sign me in](#) to login.

I Forgot my Password: If you forget your password, you can generate a new password using this link. Enter the username, click on [Forgot Password](#) link. This will send the newly generated password to the configured Email-ID for the user.

1.2 Required Browser Settings

Allow file download from this site: For Internet Explorer, choose [Tools](#) → [Internet Options](#) → [Security Tab](#), based on device setup, select among Internet, Local intranet, trusted sites and restricted sites. Click [Custom level](#). In the Security Settings - Zone dialog opened, under settings, find [Downloads](#) option, [Enable File download](#) option. Click [OK](#) to the entire dialog boxes.

For all Other Browsers, accept file download when prompted.

Enable javascript for this site: The icon indicates whether the javascript setting is enabled in browser.

Enable cookies for this site: The icon indicates whether the cookies setting are enabled in browser.

NOTE

Cookies must be enabled in order to access the website.

1.3 Default User Name and Password

Default User Name and Password Username: admin

Password: admin

NOTE

The default user name and password are in lower-case characters. When you log in using the user name and password, you get full administrative rights. It is advised to change your password once you login.

Duplicate user names shouldn't exist across various authentication methods like AD, LDAP, RADIUS or IPMI since the privilege of one Authentication method is overwritten by another authentication method when login and hence the correct privilege cannot be returned properly. Duplicate user names shouldn't be existed across different channels in IPMI.

NOTE:


Once you login to the application, it is recommended not to use the following options.

- Refresh button of the browser*
- Refresh menu of the browser*
- Back and Forward options of the browser*
- F5 on the keyboard*
- Backspace on the keyboard*

1.4 Menu Bar

The menu bar displays the following.

- Dashboard
- Sensor
- FRU Information
- Logs & Reports
- Settings
- Remote Control
- Image Redirection
- Power Control
- Maintenance
- Sign out




Menu Bar

1.5 Quick Button and Logged-in User

The user information and quick buttons are located at the top right. A screenshot of the logged-in user information is shown below.

User Information

The logged-in user information shows the logged-in user, his/her privilege and the four quick buttons allowing you to perform the following functions.



Logged-in user and its privilege level

This option shows the logged-in user name and privilege. There are five kinds of privileges.

User: Only valid commands are allowed.


Operator: All BMC commands are allowed except for the configuration commands that can change the behavior of the out-of-hand interfaces.

Administrator: All BMC commands are allowed.

No Access: Login access denied.

Notification: Click  to view the notification received.


Refresh: Click the  Refresh icon or pressing key F5 to reload the current page.

Sync: Click the  Sync icon to synchronize with Latest Sensor and Event Log updates.

Signout: Click the  icon to log out.

Warning: Click the  to view the warning messages.


Help

The Help icon () is Located at the top right of each page. Click this help icon to view more detailed field descriptions.

Chapter 2. Dashboard

The Dashboard page gives the overall information about the status of a device.

To open the Dashboard page, click [Dashboard](#) from the menu bar. A sample screenshot of the Dashboard page is shown below.



Dashboard page

A brief description of the Dashboard page is given below.

Power Cycle

This page navigates you to view the Power Control page. To view the Power Cycle Information, click [Power Cycle](#) link.

- **Up Time:** This indicates the Power on time

Pending Deassertions

It lists all the asserted events which are waiting for deassert state. To know about the pending events details, click the [More info](#) link. This navigates to the Event Log page and display all the asserted events that are waiting for deassertion.

Today & 30 Days (Event Logs)

This page displays the list of event logs occurred by the different sensors on this device. Click [Details](#) link on Today and 30 days to view the event logs for Today and 30 days respectively.


Sensor Monitoring

It lists all the critical sensors on the device. If you click on any list sensor, you can view the Sensor detail page with the Sensor information and Sensor Events details.

Chapter 3. Sensor

The Sensor Reading page displays all the sensor related information.

To open the Sensor Reading page, click [Sensor](#) from the menu. Click on any sensor to show more information about that particular sensor, including thresholds and a graphical representation of all associated events. A sample screenshot of Sensor Reading page is given below.



Sensor page

The Sensor Reading page contains the following information.

In this Sensor Reading page, Live readings for all the available sensors with details like Sensor Name, Status, Current Reading and Behaviour will be appeared, else you can choose the sensor type that you want to display from the list. Some examples for sensors are Temperature Sensors, Fan Sensors, Watchdog Sensors and Voltage Sensors etc.


Sensor detail

Select a particular Sensor from the Critical Sensor or Normal Sensor lists. The Sensor Information as Live Widget and Thresholds for the selected sensor will be displayed as shown below.

NOTE

Change Thresholds is a feature enabled option, to enable this feature refer specific PRJ (Refer MDS Guide).

For Illustrative Purpose, a sample screenshot of Sensor detail page with Change Thresholds option is shown and explained below.



Sensor detail page

NOTE

Widgets are little gadgets, which provide real time information about a particular sensor. User can track a sensor's behavior over a specific amount of time at specific intervals. The result will be displayed as a line graph in the widget. The session will not expire, until the widgets gets a live data of the last widget that is kept opened.

For the selected sensor, this widget gives a dynamic representation of the readings for the sensor. Thresholds are of six types:


- Lower Non-Recoverable (LNR)
- Lower Critical (LC)
- Lower Non-Critical (LNC)
- Upper Non-Recoverable (UNR)
- Upper Critical (UC)
- Upper Non-Critical (UNC)

The threshold states could be Lower Non-critical - going low, Lower Non-critical - going high, Lower Critical - going low, Lower Critical - going high, Lower Non-recoverable - going low, Lower Non-recoverable - going high, Upper Non-critical - going low, Upper Non-critical - going high, Upper Critical - going low, Upper Critical - going high, Upper Non-recoverable - going low, Upper Non-recoverable - going high.

A graphical view of these events (Number of Entries vs. Thresholds) can be viewed as shown in the Sensor Readings Page screenshot.

Threshold Settings

1. Click [Change Thresholds](#) to configure threshold settings. A sample screenshot is given below.



The screenshot shows a web interface titled "Sensor Thresholds". Inside, there is a form titled "Change Threshold Values" with a help icon. The form is for a sensor named "Fan_1". It contains seven input fields for different threshold levels: "Upper Non-recoverable" (7040), "Upper Critical" (3500), "Upper Non-critical" (2600), "Lower Non-critical" (560), "Lower Critical" (380), and "Lower Non-recoverable" (320). A blue "Save" button is located at the bottom right of the form.

Sensor Threshold page

1. Enter the Threshold values and click [Save](#) to configure the threshold values.

NOTE

The Threshold Settings will be enabled only for administrator or operator privilege users. For other users the Threshold Settings option will be disabled and they cant access to perform this action.


View this Event Log

You can click here to view the Logs & Reports for the selected sensor.

Chapter 4. FRU Information

FRU Information page displays the BMC's FRU device information. FRU page shows information like Basic Information, Chassis Information, Board Information and Product Information of the FRU device.

To open the FRU Information page, click [FRU Information](#) from the menu bar. Select a FRU Device ID from the FRU Information section to view the details of the selected device. A screenshot of FRU Information page is given below.



FRU Information page

The following fields are displayed here for selected device.

Available FRU Devices

- FRU device ID - Select the device ID from the drop down list
- FRU Device Name - The device name of the selected FRU device.

Chassis Information

- Chassis Information Area Format Version
- Chassis Type
- Chassis Part Number
- Chassis Serial Number
- Chassis Extra

Board Information

- Board Information Area Format Version
- Language
- Manufacture Date Time
- Board Manufacturer
- Board Product Name
- Board Serial Number
- Board Part Number
- FRU File ID
- Board Extra

Product Information


- Product Information Area Format Version
- Language
- Product Manufacturer
- Product Name
- Product Serial Number
- Product Version
- Product Serial Number
- Asset Tag
- FRU File ID
- Product Extra

Chapter 5 Logs & Reports

The Logs & Reports page displays the following information.

- IPMI Event Log
- Audit Log
- Video Log

A screenshot displaying the menu items under Logs & Reports is shown below.




Logs and Reports Menu

5.1 IPMI Event Log

This page displays the list of event logs occurred by the different sensors on this device. Double click on a record to see the details of that entry. You can use the sensor type or sensor name filter options to view those specific events or you can also sort the list of entries by clicking on any of the column headers.

To open the Event Log page, click [Logs & Reports](#) → [Event Log](#) from the menu bar. A sample screenshot of Event Log page is shown below.



Event Log Page

The Event Log page consists of the following Fields.

Filter By Date: Filtering can be done by selecting [Start Date](#) and [End Date](#) using Calendar.

Filter By Type: The category could be either All Events, System Event Records, OEM Event Records, BIOS Generated Events, SMI Handler Events, System Management Software Events, System Software - OEM Events, Remote Console Software Events, Terminal Mode Remote Console software Events.

NOTE

Once the Filter By Date and Filter type are selected, the list of events will be displayed with the Event ID, Time Stamp, Sensor Type, Sensor Name and Description.

Event Log Statistics: Displays the statistical graph for the selected date.

Clear Event Logs: To delete all the event logs.

Procedure:

1. From the Filter By Date field, select the time period by Start Date and End Date using Calendar for the event categories. The events will be displayed according to the selected date.
2. From the Filter By Type field, select the Type of the event and Sensor name to view the events for the date. The events will be displayed based on the selected time period.
3. To clear all events from the list, click [Clear All Event Logs](#).


5.2 System Log

System Log page will display all the system events occurred in this device that has been already configured.

NOTE

Logs have to be configured under Settings → Log Settings in order to display any entries.

To open the Event Log page, click [Logs & Reports](#) → [System Log](#) from the menu bar. A sample screenshot of System Log page is shown below.



System Log page

Procedure

To view System Log, click the [System Log](#) tab to view all system events. Entries can be filtered based on Filter By Date (Start Date and End Date) and Event Category like Alert, Critical, Error, Notification, Warning, Debug, Emergency and Information.


5.3 Audit Log

Audit Log page will display all the system events occurred in this device that has been already configured.

NOTE

Logs have to be configured under Settings → Log Settings → Advanced Log Settings in order to display any entries.

To open the Event Log page, click [Logs & Reports](#) → [Audit Log](#) from the menu bar. A sample screenshot of Audit Log page is shown below.



Audit Log page

Procedure

To view Audit Log, click the [Audit Log](#) tab to view all audit events for this device.

5.4 Video Log

To open the Video Log page, click [Logs & Reports](#) → [Video Log](#) from the menu bar. A sample screenshot of Video Log page is shown below.


NOTE

Video Trigger Settings should be enabled, to display the Video Log page. Video Trigger Settings can be configured under Settings → Video Recording → Auto Video Settings → Video Trigger Settings.



Chapter 6. Settings

This group of pages allows you to access various configuration settings. A screenshot of Configuration Group menu is shown below.



Configuration Group page


A detailed description of the Configuration menu is given below.

6.1 Captured BSOD

This page displays a snapshot of the blue screen captured if the host system crashed since last reboot. A screenshot of Captured BSOD is shown below.

NOTE

KVM service should be enabled to display the BSOD screen. KVM Service can be configured under Settings → Services → KVM.




6.2 External User services

6.2.1 LDAP/E-Directory Settings

The Lightweight Directory Access Protocol (LDAP)/E-Directory Settings is an application protocol for querying and modifying data of directory services implemented in Internet Protocol (IP) networks.


LDAP is an Internet protocol that MegaRAC® card can use to authenticate users. If you have an LDAP server configured on your network, you can use it as an easy way to add, manage and authenticate MegaRAC® card users. This is done by passing login requests to your LDAP Server. This means that there is no need to define an additional authentication mechanism, when using the MegaRAC® card. Since your existing LDAP Server keeps an authentication centralized, you will always know who is accessing the network resources and can easily define the user or group-based policies to control access.

To open External User Services page, click [Settings](#) → [External User Services](#) from the menu bar. A sample screenshot of External User Services page is shown below.



External User Services page

To open LDAP/E-DIRECTORY Settings page, click [Settings](#) → [External User Services](#) → [LDAP/E Directory Settings](#) from the menu bar. A sample screenshot of External User Services page is shown below.



LDAP/E Directory Settings page

The fields of LDAP/E-Directory Settings page are explained below.

General Settings: To configure LDAP/E-Directory Settings. Options are Enable LDAP/E-Directory Authentication, IP Address, Port and Search base.

Role Groups: To add a new role group to the device. Alternatively, double click on a free slot to add a role group.

Procedure

Entering the details in General LDAP/E-Directory Settings page

1. In the LDAP/E-Directory Settings page, click [General Settings](#). A sample screenshot of General LDAP Settings page is given below.

General LDAP Settings page

2. Click [Enable LDAP/E-Directory Authentication](#), to enable LDAP/E-Directory Settings.

NOTE

During login prompt, use username to login as an ldap Group member.

3. Select the encryption type for LDAP/E-Directory from the Encryption Type.

NOTE

Configure proper port number when SSL is enabled.

4. Select the Common Name Type as IP Address.

5. Enter the IP Address of LDAP server in the server address field.

NOTE

- IP Address made of 4 numbers separated by dots as in 'xxx.xxx.xxx.xxx'.
- Each number ranges from 0 to 255. First number must not be 0.
- Supports IPv4 format and IPv6 format.
- Configure FDQN address when using StartTLS with FDQN.

6. Specify the LDAP Port in the port field.

NOTE

Default port is 389. For SSL connections, default port is 636. The port value ranges from 1 to 65535.

7. Specify the Bind DN that is used during bind operation, which authenticates the client to the server.

NOTE

- Bind DN is a string of 4 to 64 alpha-numeric characters.
- It must start with an alphabetical character.
- Special symbols like dot(.), comma(,), hyphen(-), underscore(_), equal-to (=), are allowed.
- Example: cn=manager, ou=login, dc=domain, dc=com

8. Enter the password in the password field.

NOTE

- Password must be at least 1 character long.
- White space is not allowed. This field will not be allowed for more than 48 characters.

9. Enter the search base. The search base tells the LDAP server which part of the external directory tree to search. The search base may be something of equivalent to the organization, group of external directory.

NOTE

- Search base is a string of 4 to 63 alpha-numeric characters.
- It must start with an alphabetical character.
- Special symbols like dots (.), comma(,), hyphen(-), underscore(_), equal-to(=) are allowed.
- Example: ou=login,dc=domain,dc=com

10. Select [Attribute of User Login](#) to find the LDAP/E-Directory server which attribute should be used to identify the user.

NOTE

It only supports cn or uid.

11. Select CA Certificate File from the browse field to identify the certificate of the trusted CA certs.

12. Select the [Certificate File](#) to find the client certificate filename.

13. Select [Private Key](#) to find the client private key filename.

NOTE

All the 3 files are required, when StartTLS is enabled.

14. Click [Save](#) to save the settings.

To add a new Role Group

1. In the LDAP/E-Directory Settings page, click [Role Groups](#) and select a blank row.
2. Click [Add Role Group](#) or alternatively double click on the blank row to open the Add Role group page as shown in the screenshot below.

Add Role Group page

3. In the Group Name field, enter the name that identifies the role group.

NOTE

Role Group Name is a string of 255 alpha-numeric characters. Special symbols hyphen and underscore are allowed.

4. In the Group Domain field. Enter the Role Group Domain where the role group is located.

NOTE

- Domain Name is a string of 4 to 64 alpha-numeric characters.
- It must start with an alphabetical character.
- Special Symbols like dot(.), comma(,), hyphen(-), underscore(_), equal-to(=) are allowed.
- Example: cn=manager,ou=login, dc=domain,dc=com

5. In the Group Privilege field, enter the level of privilege (User, Administrator, Operator, None) to assign to this role group.
6. Select the required options or both
 - KVM Access
 - VMedia Access
7. Click [Save](#) to save the new role group and return to the Role Group List.

6.2.2 Active Directory Settings


An active directory is a directory structure used on Microsoft Windows based computers and servers to store information and data about networks and domains. An active directory (sometimes referred to as AD) does a variety of functions including the ability to provide information on objects. It also helps to organize these objects for easy retrieval and access, allows access by end users and administrators and allows the administrator to set security up for the directory.

Active Directory allows you to configure the Active Directory Server Settings. The displayed table shows any configured Role Groups and the available slots. You can modify, add or delete role groups from here. Group domain can be the AD domain or a trusted domain. Group Name should correspond to the name of an actual AD group.

NOTE

To view the page, you must be at least a User and to modify or add a group, you must be an Administrator.

To open Active Directory Settings page, click [Settings](#) → [External User Settings](#) → [Active Directory](#) from the menu bar. A sample screenshot of Active Directory Settings page is shown below.



Active Directory page

The fields of Active Directory page are explained below.

General Settings: This option is used to configure Active Directory General Settings. Options are Enable Active Directory Authentication, Secret User Name, Secret Password, User Domain name, and up to three Domain Controller Server Addresses.

Role Groups: To add a new role group to the device. Alternatively, double click on a free slot to add a role group.

Procedure:

Enter the details in General Active Directory Settings page.

1. Click on [General Settings](#) to open the General Active Directory Settings page.

General Active Directory Settings Page

2. In Active Directory Setting page, check or uncheck [Authentication](#) respectively.

NOTE

If you have enabled Active Directory Authentication, enter the required information to access the Active Directory server.

3. Specify the secret user name and password in the Secret User Name and Secret Password respectively.

NOTE

- Secret username/password for AD is not mandatory. When secret username & password is empty, Authentication fails will be always treated as Invalid Password error. For Invalid Password error PAM will not try other Authentication Methods. So it is recommended to keep AD in the last location in PAM order.
- User Name is a string of 1 to 64 alpha-numeric characters.
- It must start with an alphabetical character.
- It is case-sensitive.
- Special characters like comma, period, colon, semicolon, slash, backslash, square brackets, angle brackets, pipe, equal, plus, asterisk, question mark, ampersand, double quotes, space are not allowed.
- Password must be at least 6 character long and will not allow more than 127 characters.
- White space is not allowed.

4. Specify the Domain Name for the user in the User Domain field. E.g. MyDomain.com

5. Configure IP addresses in Domain Controller Server Address1, Domain Controller Server Address2 and Domain Controller Server Address3

NOTE


IP address of Active Directory server: At least one Domain Controller Server Address must be configured.

- IP Address made of 4 numbers separated by dots as in "xxx.xxx.xxx.xxx".
- Each number ranges from 0 to 255.
- First number must not be 0.
- Domain Controller Server Addresses will supports IPv4 Address format and IPv6 Address format.

6. Click [Save](#) to save the entered settings and return to Active Directory Settings page.

Role Groups

To open Role Group page, click [Settings](#) → [External User Settings](#) → [Active Directory](#) → [Role Groups](#) from the menu bar. A sample screenshot of Role Groups page is shown below.



Role Groups page

The fields of Role Group page are explained below.

Role Group Name: The name that identifies the role group in the Active Directory.

NOTE

- Role Group Name is a string of 64 alpha-numeric characters.
- Special symbols hyphen and underscore are allowed.

Group Name: This name identifies the role group in Active Directory.

NOTE

- Role Group Name is a string of 64 alpha-numeric characters.
- Special symbols hyphen and underscore are allowed.

Group Domain: The domain where the role group is located.

NOTE

- Domain Name is a string of 255 alpha-numeric characters.
- Special symbols hyphen, underscore and dot are allowed.

Group Privilege: The level of privilege to assign to this role group.

KVM Access: To provide access to KVM for AD authenticated role group user.

VMedia Access: To provide access to VMedia for AD authenticated role group user.

To add a new Role Group

1. In the Active Directory Settings page, select a Role Group and click [Add Role Group](#) or alternatively double click on the blank row to open the Add Role group page as shown in the screenshot below.

The screenshot shows the 'Role Groups' page in a web application. On the left, there is a form for adding a new role group. The form has the following fields: 'Group Name' (a text input field), 'Group Domain' (a text input field with the example 'eg. dc:domain' below it), 'Group Privilege' (a dropdown menu currently showing 'User'), and two checkboxes: 'KVM Access' and 'VMedia Access'. At the bottom of the form are two buttons: a red 'Delete' button and a blue 'Save' button. The breadcrumb navigation at the top right reads: Home > Settings > External User Settings > Active Directory Settings > Role Groups > Role Group.

Role Groups page

2. In the Group Name field, enter the name that identifies the role group in the Active Directory.

NOTE

- Role Group Name is a string of 64 alpha-numeric characters.
- Special symbols hyphen and underscore are allowed.

3. In the Group Domain field, enter the domain where the role group is located.

NOTE

- Domain Name is a string of 255 alpha-numeric characters.
- Special symbols hyphen, underscore and dot are allowed.

4. In the Group Privilege field, enter the level of privilege to assign to this role group.
5. Select the required options
 - KVM Access
 - VMedia Access
6. Click [Save](#) to add the new role group and return to the Role Group List.


To Delete a Role Group

1. In the Role Groups page, select the row that you wish to delete.
2. Click [Delete Role Group](#).

6.2.3 RADIUS Settings

RADIUS is a modular, high performance and feature-rich RADIUS suite including server, clients, development libraries and numerous additional RADIUS related utilities. This page is used to set the RADIUS Authentication.

To open RADIUS Settings page, click [Settings](#) → [External User Settings](#) → [RADIUS Settings](#) from the menu bar. A sample screenshot of RADIUS Settings page is shown below.



General RADIUS Settings

 A screenshot of the "General RADIUS Settings" form. The breadcrumb trail is "Home > Settings > External User Settings > RADIUS Settings > General RADIUS Settings". The form contains:

- Enable RADIUS Authentication
- Server Address:
- Port:
- Secret:
- Enable KVM Access
- Enable VMedia Access
-

General RADIUS Settings page

The fields of General RADIUS Settings page are explained below.

Enable RADIUS Authentication: Option to enable/disable RADIUS authentication.

Server Address: The IP address of RADIUS server.

NOTE

- IP Address (Both IPv4 and IPv6 format).
- FQDN (Fully Qualified Domain Name) format.

Port: The RADIUS Port number.

NOTE

- Default Port is 1812.
- Port value ranges from 1 to 65535.

Secret: The Authentication Secret for RADIUS server.

NOTE

- This field will not allow more than 31 characters.
- Secret must be at least 4 characters long.
- White space is not allowed.

Enable KVM Access: This field provides access to KVM for RADIUS authenticated users.

Enable VMedia Access: This field provides access to VMedia for RADIUS authenticated users.

Save: To save the settings.

Procedure

1. Enable the [RADIUS Authentication](#) check box to authenticate the RADIUS.
2. Click [Advanced RADIUS Settings](#). This opens the Radius Authorization window as shown below.

Advanced RADIUS Settings

For Authorization Purpose, configure the Radius user with Vendor Specific Attribute in Server side.

Example:1

```
testadmin Auth-Type :=PAP,Cleartext-Password:="admin"
```

```
Auth-Type :=PAP, Vendor-Specific="H=4"
```

Example:2

```
testoperator Auth-Type := PAP,Cleartext-Password := "operator"
```

```
Auth-Type :=PAP, Vendor-Specific="H=3"
```


If you change the Vendor-Specific value in server then you should change the same values in this page.

3. Click [Save](#) to save the changes made.

6.3 KVM Mouse Settings

Redirection Console handles mouse emulation from local window to remote screen in either of three methods. User has to be an Administrator to configure this option. To view the Supported Operating Systems for Mouse Mode, click [Mouse Mode](#).

To open KVM Mouse setting page, click [Settings](#) → [KVM Mouse Setting](#) from the menu bar. A sample screenshot of KVM Mouse Settings page is shown below.



KVM Mouse Settings page

The fields of KVM Mouse Settings page are explained below.

Mouse Mode Settings Page

The fields of KVM Mouse Settings page are explained below.

Relative Positioning (Linux): Relative mode sends the calculated relative mouse position displacement to the server.

Absolute Positioning (Windows): The absolute position of the local mouse is sent to the server.

Other Mode (SLES-11 OS Installation): To have the calculated displacement from the local mouse in the center position sent to the server.

Save: To save the changes made.

Procedure

1. Choose either of the following as your requirement:

- Set mode to Absolute

NOTE

Applicable for all Windows versions, versions above RHEL6, and versions above FC14.

- Set mode to Relative

NOTE

Applicable for all Linux versions, versions less than RHEL6, and versions less than FC14.

- Set Mode to Other Mode

NOTE


Recommended for SLES-11 OS Installation

2. Click [Save](#) button to save the changes made.

6.4 Log Settings

System and Audit log page displays a list of system logs and audit logs occurred in this device.

To open Log Settings page, click [Settings](#) → [Log Settings](#) from the menu bar. A sample screenshot of Log Settings page is shown below.




System and Audit Log Settings

The fields of Log Settings page are explained below.

- Log Settings Policy
- Advanced Log Settings

6.4.1 Log Settings Policy

To open Log Settings page, click [Settings](#) → [Log Settings](#) → [Log Settings Policy](#) from the menu bar. A sample screenshot of Log Settings Policy page is shown below.



Log Settings Policy page

This page is used to configure the log policy for the event log. The fields are as followed.

Log Policy: This field is to enable or disable the Linear Storage Policy or Circular Storage Policy.

Save: To save the configured settings.

6.4.2 Advanced Log Settings

To open Advanced Log Settings page, click [Settings](#) → [Log Settings](#) → [Advanced Log Settings](#) from the menu bar. A sample screenshot of Advanced Log Settings Policy page is shown below.

Advanced Log Settings page

This page is used to configure the log policy for the event log. The fields are as followed.

Enable System Log: This field is to enable or disable the System Logs.

Location: Specifies the Location for system logs, whether it should be preserved in a Local Log/Remote Log.

Local Log: Select Local Log to save the logs locally (BMC).

NOTE

Local file resides at /var/log/

Rotate Count: To back up the log information in back up files.

NOTE

- Value ranges from 0 to 255.
- When log information exceeds the file size, the old log information is automatically moved to back up files based on the rotate count value. If rotate count is zero, then old log information gets cleared permanently.
- File Size and Rotate Count options will be available only when Local Log is enabled.

Remote Server Port: This field is to specify the Remote Server port address to log the system events.

NOTE

Remote Log Server and Remote Server Port options will be available only when Remote Log is enabled.

Enable Audit Log: To enable or disable the audit log.

Save: To save the changes.

Procedure

1. In the System Log field, enable or disable the option.
2. Select the Log type: [Local Log](#) or [Remote Log](#).
3. If Local log is selected, enter the file size in the File Size field and rotate count in the Rotate Count field.

NOTE

If Remote log is selected, the fields file size and rotate count need not be mentioned.

4. If remote log is selected, specify the Server Address of the remote server where the system events are logged.
5. In the Audit Log field, check or uncheck the [Enable](#) option as desired.
6. Click [Save](#) to save the changes.

Steps to configure the remote server to enable syslogging


NOTE

This example uses FC13 as the remote machine to log syslog. On FC machine, disable the following lines for UDP in `/etc/rsyslog.conf`.

1. `MODLOAD imudp`
2. `UDPSERVER 514`

6.5 Media Redirection Settings

To open KVM Mouse setting page, click [Settings](#) → [KVM Mouse Setting](#) from the menu bar. A sample screenshot of KVM Mouse Settings page is shown below.



Media Redirection Settings page


The fields of Media Redirection page are explained below.

- General Settings
- VMedia Instance Settings

6.5.1 General Settings

This option is used to configure General Media Settings.

To open General Media Settings section, click [Settings](#) → [Media Redirection Settings](#) → [General Settings](#).



General Settings page

Local Media Support: To enable or disable Local Media support, check/uncheck the 'Enable' check box.

Remote Media Support: To enable or disable Remote Media support, check/uncheck the 'Enable' check box.

Mount CD/DVD: To enable or disable Mount CD/DVD support, check/uncheck the 'Enable' check box.

NOTE

You can also select all the media types simultaneously.

Server Address for CD/DVD Images: Displays the address of the server where the remote media images are stored.

Path in server: Displays the Source path to the remote media images.

Share Type for CD/DVD: Displays the Share Type of the remote media server either NFS or CIFS.

Domain Name, Username, and Password: If share Type is Samba(CIFS), then enter user credentials to authenticate on the server.

Same settings for Floppy/Harddisk Images: Enable/Disable to select same media type data configurations for all the remote media types.

Mount Floppy: Enable/Disable to Mount Floppy.

Server Address for Floppy Images: Address of the server where the remote media images are stored.

Path in server: Source path to the remote media images. **Share Type for Floppy:** To Select Share Type for Floppy. **Mount Harddisk:** Enable/Disable to Mount Harddisk.

Server Address for Harddisk Images: Address of the server where the remote media images are stored.

Share Type for Floppy: To Select Share Type for Floppy.

Mount Harddisk: Enable/Disable to Mount Harddisk.

Path in server: Source path to the remote media images.

Share Type for Harddisk: To Select Share Type for Floppy.

Save: To save the settings.

6.5.2 VMedia Instance Settings

This page is used to configure Virtual Media device settings. To open VMedia Instance Settings page, click [Settings](#) → [Media Redirection Settings](#) → [VMedia Instance Settings](#) from the menu bar.

A sample screenshot of VMedia Instance Settings Page is shown below.

VMedia Instance Settings

Home > Settings > Media Redirection > VMedia Instance Settings

Floppy device instances
4

CD/DVD device instances
4

Hard disk instances
4

Remote KVM Floppy device instances
2

Remote KVM CD/DVD device instances
2

Remote KVM Hard disk instances
2

Emulate SD Media as USB disk to Host

Encrypt Media Redirection Packets

Power Save Mode

Save

VMedia Instance Settings

The following fields are displayed in this page.

Floppy device instances: The number of floppy devices supported for Virtual Media redirection.

CD/DVD device instances: The number of CD/DVD devices supported for Virtual Media redirection.

Harddisk instances: The number of harddisk devices supported for Virtual Media redirection.

Remote KVM Floppy devices instances: The number of floppy devices supported for KVM Virtual Media redirection.

Remote KVM CD/DVD device instances: The number of CD/DVD devices supported for Virtual Media redirection.

Remote KVM Hard disk instances: The number of Hard disk devices supported for Virtual Media redirection.

Emulate SD Media as USB disk to Host: To emulate SD Media on BMC as a USB device to Host Server.

Power Save Mode: To enable or disable the virtual USB devices visibility in the host. If this option is enabled, Virtual media devices will be connected to the Host machine only at the instance launching KVM session. If this option is disabled, Virtual media devices will remain connected to the host machine all the time irrespective of KVM session status.

Save: To save the configured settings.

NOTE

Virtual Media configuration changes will restart all the media services. So configuration changes be blocked when any active media redirection is present.

Procedure

1. Select the number of Floppy devices, CD/DVD devices, Harddisk devices and Remote KVM Floppy, CD/DVD and Hard disk Devices from the respective drop-down list.

NOTE

Maximum of four devices can be added in Floppy, CD/DVD and Harddisk drives.

2. Select the Emulate SD Media as USB disk to Host option to enable/disable the SD cards support in the host.
3. Check the Power Save Mode option to enable/disable the Virtual USB devices visibility in the host.
4. Click [Save](#) to save the changes made else click [Reset](#) to reset the previously saved values.

NOTE

If there are two device panels for each device, and when you click the [Connect](#) button, then the redirected device panel will be disabled.

Unmounting device will make the driver disconnect device when using Auto Attach. Hence, when unmounting one USB key, the other USB key will be disconnected and then reconnected.

6.5.3 Remote Session

This page is used to configure virtual media configuration settings for the next redirection session. “KVM Single Port Application” is enabled by default. While disabling, “KVM Single Port Application” and “Encrypt H5Viewer KVM packets” are disabled by default.

To open Remote Session page, click [Settings](#) → [Media Redirection Settings](#) → [Remote Session](#) from the menu bar. A sample screenshot of Remote Session page is shown below.

Remote Session page

The fields of Configure Remote Session page are explained below.

KVM Single Port Application: To Enable/Disable single port support by runtime, On changing this configuration, KVM and VMedia Sessions will be restarted. If this support is enabled, KVM session will not use its dedicated port whereas both Web and KVM sessions will be established only via Web Port. If this support is disabled, KVM and Web sessions will use their own dedicated ports respectively.

Encrypt H5Viewer KVM packets: To Enable/Disable Encryption of KVM data for the next redirection session. If KVM Encryption is enabled, the KVM session will use the Secure port which has been configured in Settings → Services Page. If KVM Encryption is disabled, the KVM session will use the Non-Secure port which has been configured in Settings → Services Page.

NOTE

This option is disabled if Single Port is enabled.

Keyboard Language: This option is used to select the keyboard supported languages.

Retry Count: This value specifies the number of attempts the KVM client will make to reconnect the KVM session. The retry count value ranges from 1 to 20.

Retry Time Interval(Seconds): This option is used to give time interval for each attempts.

Server Monitor OFF Feature Status: To enable/disable Server Monitor OFF. If this option is enabled, you can Lock or Unlock the Local host monitor from the remote KVM window. If this option is disabled, you cannot Lock or Unlock the Local host monitor from the remote KVM window.

Automatically OFF Server Monitor, When KVM Launches: To enable/disable Automatically OFF Server Monitor, When KVM Launches.

Save: To save the current changes.

NOTE

It will automatically close the existing remote redirection either KVM or Virtual media sessions, if any.

Procedure


1. Check or uncheck the [KVM Single Port Application/Encrypt H5Viewer KVM packets](#) option enable Single Port Application support in BMC when using H5Viewer.
2. Choose the Keyboard Language from the list of keyboard supported languages.
3. Enter a value in the Retry Count field to set the number of attempts for retrying the redirection session.
4. Enter a value in the Retry Time Interval(Seconds) field to give time interval for each attempts.
5. Check the [Server Monitor OFF Feature Status](#) check box to enable Local Monitor ON/OFF command during runtime.
6. Check the [Automatically OFF Server Monitor, When KVM Launches](#) check box to automatically Lock the local monitor during H5Viewer launch.
7. Click [Save](#) to save the current changes.

6.6 Network Settings

The Network Settings page is used to configure the network settings for the available LAN channels.

6.6.1 Network IP Settings

To open Network Settings page, click [Settings](#) → [Network Settings](#) → [Network IP Settings](#) from the menu bar. A sample screenshot of Network IP Settings page is shown below.



Network IP Settings page

The fields of Network IP Settings page are explained below.

Enable LAN: To enable or disable the LAN Settings.

LAN Interface: Lists the LAN interfaces.

MAC Address: This field displays the MAC Address of the device. This is a read only field.

Enable IPv 4: This option is to enable/disable the IPv4 settings in the device.

Enable IPv4 DHCP: This option is to enable IPv4 DHCP support for the selected interface.

IPv4 Address, IPv4 Subnet Mask , and IPv4 Default Gateway: These fields are for specifying the static IPv4 address, Subnet Mask and Default Gateway to be configured to the device.

NOTE

- IP Address made of 4 numbers separated by dots as in "xxx.xxx.xxx.xxx".
- Each Number ranges from 0 to 255.
- First Number must not be 0.

Enable IPv6: To Enable/Disable the IPv6 configuration settings.

Enable IPv6 DHCP: To Enable/Disable the IPv6 settings in the device. It dynamically configures IPv6 address using DHCP (Dynamic Host Configuration Protocol).

IPv6 Index: To specify a static IPv6 Index to be configured to the device. Eg: 0

IPv6 Address: To specify a static IPv6 address to be configured to the device. Eg: 2004::2010

Subnet Prefix length: To specify the subnet prefix length for the IPv6 settings.

NOTE

Value ranges from 0 to 128.

Default Gateway: Specify v6 default gateway for the IPv6 settings.

NOTE

If core feature IPV6_COMPLIANCE and SUPPORT_IPMIIPV6_LAN_PARAM_ONLY are enabled, the IPv6 default Gateway field will not be displayed.

Enable VLAN: To enable/disable the VLAN support for selected interface.

VLAN ID: The Identification for VLAN configuration.

NOTE

Value ranges from 2 to 4094.

VLAN Priority: The priority for VLAN configuration.

NOTE

- Value ranges from 0 to 7.
- 7 is the highest priority for VLAN.

Save: To save the entries.

Procedure

1. Check [Enable LAN](#) to enable LAN support for the selected interface..
2. Select the LAN Interface to be configured.
3. Check [Enable IPv4](#) to enable IPv4 support for the selected interface.
4. Check [Enable IPv4 DHCP](#) to dynamically configure IPv4 address using DHCP.
5. If the field is disabled, enter the IPv4 Address , IPv4 Subnet Mask and IPv4 Default Gateway in the respective fields.
6. In IPv6 Configuration, if you wish to enable the IPv6 settings, check [Enable IPv6](#).
7. If the IPv6 setting is enabled, enable or disable the option [Enable IPv6 DHCP](#).
8. If the field is disabled, enter the IPv6 Address, Subnet Prefix length and IPv6 Index in the given field.
9. In VLAN Configuration, if you wish to enable the VLAN settings, check [Enable LAN](#).
10. Enter the VLAN ID in the specified field.
11. Enter the VLAN Priority in the specified field.
12. Click [Save](#) to save the entries.


6.6.2 Network Bond Configuration

This page is used to configure the network bonding configuration for the network interfaces.

NOTE

Minimum of two network interfaces required to enable Network bonding for the device.

To open Network Settings page, click [Settings](#) → [Network Settings](#) → [Network Bond](#) from the menu bar. A sample screenshot of Network Bonding page is shown below.



Network Bond Configuration page

The fields of Network Bond Configuration page are explained below.

Enable Bonding: To enable or disable network bonding for network interfaces.

Auto Configuration: To configure the interfaces in service configuration automatically.

NOTE

If Auto configuration is disabled, then interfaces in services can be configured via IPMI command.

If Auto configuration is enabled, then all the services will be restarted automatically.

Bond Mode: This field displays the Network bonding mode.

NOTE

This field cannot be configured.

Save: To save the current changes.

Procedure:**NOTE**

The Enable Bonding option is enabled. You can disable the option if needed.

1. Select the [Bond Interface](#) from the drop-down list.

NOTE


The Bond Interface can be selected only if the Enable Bonding option is enabled.

2. Check the [Auto Configuration](#) option to enable the auto configuration.
3. Click [Save](#) to save the configuration.

6.6.3 Network Link

This page is used to configure the network link configuration for available network interfaces.

To open Network Link page, click [Settings](#) → [Network Settings](#) → [Network Link](#) from the menu bar. A sample screenshot of Network Link Configuration page is shown below.



Network Link page

The fields of Network Link Configuration page are explained below.

LAN Interface: Select the required network interface from the list to which the Link speed and duplex mode to be configured.

Auto Negotiation: This option is enabled to allow the device to perform automatic configuration to achieve the best possible mode of operation (speed and duplex) over a link.

Link Speed: Link speed will list all the supported capabilities of the network interface. It can be 10/100/1000 Mbps.

NOTE

Link speed of 1000 Mbps is not applicable, when Auto Negotiation is OFF.

Duplex Mode: Duplex Mode could be either Half Duplex or Full Duplex.

Save: To save the settings.

Procedure:

1. Select the [LAN Interface](#) from the drop down list.
2. Select either [Enable](#) or [Disable](#) for Auto Negotiation.

NOTE

The Link Speed and Duplex Mode will be active only when Auto Negotiation is OFF.


3. Select the [Link Speed](#) from the drop-down list.
4. Select the Duplex Mode either [Full duplex](#) or [Half duplex](#).
5. Click [Save](#) to save the configuration.

6.6.4 DNS Configuration

The Domain Name System (DNS) is a distributed hierarchical naming system for computers, services, or any resource connected to the Internet or a private network. It associates the information with domain names assigned to each of the participants. Most importantly, it translates domain names meaningful to humans into the numerical (binary) identifiers associated with networking equipment for the purpose of locating and addressing these devices worldwide.

The DNS Server settings page is used to manage the DNS settings of a device.

To open DNS Server Settings page, click [Settings](#) → [Network Settings](#) → [DNS Configuration](#) from the menu bar. A sample screenshot of DNS Configuration page is shown below.



DNS Server Configuration page

The fields of DNS Configuration page are explained below.

Domain Name Service Configuration

DNS Enabled: To enable/disable all the DNS Service Configurations. mDNS Enable: To enable/disable the mDNS Support Configurations.

mDNS Enable: To enable/disable the mDNS Support Configurations.

Host Name Settings: Choose either Automatic or Manual settings.

Host Name: It displays host name of the device. If the Host setting is chosen as Manual, then specify the host name of the device.

NOTE

- Value ranges from 1 to 64 alpha-numeric characters.
- Special characters '-'(hyphen) and '_'(underscore) are allowed.
- It must not start or end with a '-'(hyphen). IE browsers won't work correctly if any part of the host name contain underscore (_) character.

BMC Registration Settings

BMC Interface: Options to register the BMC are through an Interface.

Register BMC: To register BMC through registration method.

Registration Method

Options to register the BMC are through NS Update or DHCP Client FQDN or Hostname.

TSIG Authentication Enabled: Check this box to enable TSIG authentication while registering DNS via nsupdate. Separate TSIG files can be uploaded for each LAN interface.

Current TSIG Private File: The information of Current TSIG private file along with its uploaded date/time will be displayed (read only).

New TSIG Private File: Browse and navigate to the TSIG private file.

NOTE

TSIG file should be of private type.

Domain Setting: Select whether the domain interface will be configured manually or automatically.

- **Automatic** - If you Select Automatic, the Domain Name cannot be configured as it will be done automatically. The field will be disabled.
- **Manual** - If the Domain setting is chosen as Manual, then specify the domain name of the device.

NOTE

If you select "Automatic" it displays the Domain Interface option. If you select "Manual" it displays "Domain name".

- **Domain Name:** It displays the domain name of the device.

Domain Name Server Setting

- **Automatic** - If you select Automatic “DNS Interface” option should be explained.
- **Manual** - Specify the DNS (Domain Name System) server address to be configured for the BMC.

IP Priority:

- If IP Priority is IPv4, it will have 2 IPv4 DNS servers and 1 IPv6 DNS server.
- If IP Priority is IPv6, it will have 2 IPv6 DNS servers and 1 IPv4 DNS server.

NOTE

This is not applicable for Manual configuration.

DNS Server 1, 2 & 3

To specify the DNS (Domain Name System) server address to be configured for the BMC.

NOTE

- IPv4 Addresses should be given in dotted decimal representation.
- IPv6 Addresses are supported and must be global unicast addresses.

DNS Server Address will support the following:

- IPv4 Address format.
- IPv6 Address format.

Save: To save the entered changes.

Procedure:

1. In Domain Name Service Configuration, Enable DNS Service.
 - Check the option **DNS Enabled** to enable all the DNS Service Configurations.
2. Choose the Host Name Setting either Automatic or Manual.

NOTE

If you choose Automatic, you need not enter the Host Name and if you choose Manual, you need to enter the Host Name.

3. Enter the Host Name in the given field if you have chosen Manual Configuration.
4. Under Register BMC, choose the BMC’s network port to register with DNS settings.
 - Check **Register BMC** option to register with DNS settings.
 - **Nsupdate** - Choose Nsupdate option to register with DNS server using nsupdate application.
 - **DHCP Client FQDN** - Choose DHCP Client FQDN option to register with DNS Server using DHCP option 81.
 - **Hostname** - Choose Hostname option to register with DNS server using DHCP option.

NOTE


Hostname option should be selected, if the DHCP client FQDN option is not supported by DHCP server.

5. In TSIG Configuration, Check the option [TSIG Authentication Enabled](#).
 - The current file name will be displayed in Current TSIG Private file.
 - To view a new one, browse and navigate to the TSIG private file.
6. In the Domain Settings,
 - Select the domain settings ([Automatic](#) or [Manual](#)).
 - Enter the Domain Name in the given field if the option “Manual” is being selected in domain settings field.
7. In Domain Name Server Setting,
 - Select the DNS Name Server Setting.
 - Choose the IP Priority, either IPv4 or IPv6.
 - Enter the DNS Server address.
8. In DNS Server1, DNS Server2 and DNS Server3, enter the server addresses to be configured for the BMC.
9. Click [Save](#) to save the entries.

6.6.5 NC-SI Configuration

This page is used to configure Network Controller Sideband Interface (NCSI) configuration settings.

To open NCSI page, click [Settings](#) → [Network Settings](#) → [NC-SI Configuration](#) from the menu bar. A sample screenshot of NCSI page is shown below.



NC-SI Configuration page

The following fields are displayed in this page.

NCSI Mode: To Select the NCSI Mode either [Auto Failover Mode](#) or [Manual Switch mode](#).

NCSI Interface: It lists the interface name in list box.

Channel Number: Lists the channel number of the selected interface.

Package ID: Lists the package id of the selected interface.

Save: To save the current changes.

Procedure

1. Select NCSI Mode type either [Auto Failover Mode](#) or [Manual Switch Mode](#).

NOTE


- If you select Auto Failover Mode, the NCSI Interface will be configured automatically.
- If you select Manual Switch Mode only you are allowed to configure NCSI Interface, Channel number and Package ID.

2. Choose the particular NCSI Interface to which you need to configure NCSI settings.
3. Choose the Channel Number to be configured for the selected Interface name.
4. Choose the Package ID to be configured for the selected Interface name.
5. Click [Save](#) to save the current changes.

6.7 PAM Order Settings

This page is used to configure the PAM ordering for user authentication in to the BMC.

To open PAM Ordering page, click [Settings](#) → [PAM Order Settings](#) from the menu bar. A sample screenshot of PAM Order page is shown below.



PAM order page

The fields of Settings → PAM Ordering page are explained below.

PAM Module: It shows the list of available PAM modules supported in BMC.

NOTE

If AD contains secret username & password as empty, Authentication fails will be always treated as Invalid Password error. For Invalid Password error PAM will not try other Authentication Methods. So it is recommended to keep AD in the last location in PAM order.

Procedure

1. Select the required PAM module and click and drag the required PAM module. It can be moved UP or DOWN to change its arrangement order.
2. Click [Save](#) to save any changes made.

NOTE

Whenever the configuration is modified, the web server will be restarted automatically. Logged-in session will be logged out.

6.8 Platform Event Filter

Platform Event Filter (PEF) provides a mechanism for configuring the BMC to take selected actions on event messages that it receives or has internally generated. These actions include operations such as system power-off, system reset, as well as triggering the generation of an alert.

The PEF Management is used to configure the following

- Event Filters
- Alert Policies
- LAN Destinations

To open PEF Management Settings page, click [Settings](#) → [Platform Event Filter](#) the menu bar. Each tab is explained below.

6.8.1 Event Filters

A PEF implementation is recommended to provide at least 40 entries in the event filter table. A subset of these entries should be pre-configured for common system failure events, such as over- temperature, power system failure, fan failure events, etc. Remaining entries can be made available for 'OEM' or System Management Software configured events. Note that individual entries can be tagged as being reserved for system use - so this ratio of preconfigured entries to run-time configurable entries can be reallocated if necessary.

PEF ID	Status	Description
PEF ID: 1	Enabled	when All Sensors switches to any severity run Alert (1) & none
PEF ID: 2	Enabled	when All Sensors switches to any severity run Alert (2) & none
PEF ID: 3	Enabled	when All Sensors switches to any severity run Alert (3) & none
PEF ID: 4	Enabled	when All Sensors switches to any severity run Alert (4) & none
PEF ID: 5	Enabled	when All Sensors switches to any severity run Alert (5) & none
PEF ID: 6	Enabled	when All Sensors switches to any severity run Alert (6) & none
PEF ID: 7	Enabled	when All Sensors switches to any severity run Alert (7) & none
PEF ID: 8	Enabled	when All Sensors switches to any severity run Alert (8) & none
PEF ID: 9	Enabled	when All Sensors switches to any severity run Alert (9) & none
PEF ID: 10	Enabled	when All Sensors switches to any severity run Alert (10) & none
PEF ID: 11	Enabled	when All Sensors switches to any severity run Alert (11) & none
PEF ID: 12	Enabled	when All Sensors switches to any severity run Alert (12) & none
PEF ID: 13	Enabled	when All Sensors switches to any severity run Alert (13) & none
PEF ID: 14	Enabled	when All Sensors switches to any severity run Alert (14) & none
PEF ID: 15	Enabled	when All Sensors switches to any severity run Alert (15) & none
PEF ID: 16	-	when switches to any severity run & none
PEF ID: 17	-	when switches to any severity run & none
PEF ID: 18	-	when switches to any severity run & none
PEF ID: 19	-	when switches to any severity run & none
PEF ID: 20	-	when switches to any severity run & none
PEF ID: 21	-	when switches to any severity run & none
PEF ID: 22	-	when switches to any severity run & none
PEF ID: 23	-	when switches to any severity run & none
PEF ID: 24	-	when switches to any severity run & none
PEF ID: 25	-	when switches to any severity run & none
PEF ID: 26	-	when switches to any severity run & none
PEF ID: 27	-	when switches to any severity run & none
PEF ID: 28	-	when switches to any severity run & none
PEF ID: 29	-	when switches to any severity run & none
PEF ID: 30	-	when switches to any severity run & none
PEF ID: 31	-	when switches to any severity run & none
PEF ID: 32	-	when switches to any severity run & none
PEF ID: 33	-	when switches to any severity run & none
PEF ID: 34	-	when switches to any severity run & none
PEF ID: 35	-	when switches to any severity run & none
PEF ID: 36	-	when switches to any severity run & none
PEF ID: 37	-	when switches to any severity run & none
PEF ID: 38	-	when switches to any severity run & none
PEF ID: 39	-	when switches to any severity run & none
PEF ID: 40	-	when switches to any severity run & none

Event Filters page

Platform Event Filters

The fields of Platform Event Filters Tab are explained below.

This page contains Pre-configured 40 Events with PEF IDs.

Procedure:

1. Click the [Event Filters](#) section to configure the event filters in the available slots.
2. To Add an Event Filter entry, select a free section to open the Event Filter entry page. A sample screenshot of Event Filter Configuration page is shown below.

Event Filters Configuration page

Event Filter Configuration

In the Event Filter Configuration section,

- In Enable this filter, check this option to enable the PEF settings.
- In Event Security to trigger, select any one of the Event security from the list..
- Select any one of the Power Action either [Power down](#), [Power reset](#) or [Power cycle](#) from the drop down list.
- Choose any one of the configured Alert Policy Group Number from the drop down list.

NOTE

Alert Policy has to be configured - under Settings → PEF → Alert Policy.

- Check [Raw Data](#) option to fill the Generator ID with raw data.
- Generator ID 1 field is used to give raw generator ID1 data value.
- Generator ID 2 field is used to give raw generator ID2 data value.

NOTE

In RAW data field, specify hexadecimal value prefix with '0x'.

- In the Event Generator section, choose the event generator as Slave Address - if event was generated from IPMB. Otherwise as System Software ID - if event was generated from system software.
- In the Slave Address/Software ID field, specify corresponding I2C Slave Address or System Software ID.
- Choose the particular Channel Number that event message was received over. Or choose '0' if the event message was received via the system interface, primary IPMB, or internally generated by the BMC.
- Choose the corresponding IPMB Device LUN if event generated by IPMB.
- Select the Sensor Type of sensor that will trigger the event filter action.
- In the Sensor Name field, choose the particular sensor from the sensor list.
- Choose Event Option to be either All Events or Sensor Specific Events.
- Event Trigger field is used to give Event/Reading type value.

NOTE

Value ranges from 1 to 255.

- Event Data 1 AND Mask field is used to indicate wildcarded or compared bits.

NOTE

Value ranges from 0 to 255.

- Event Data 1 Compare 1 & Event Data 1 Compare 2 fields are used to indicate whether each bit position's comparison is an exact comparison or not.

NOTE

Value ranges from 0 to 255.

- Event Data 2 AND Mask field is similar to Event Data 1 AND Mask.

- Event Data 2 Compare 1 & Event Data 2 Compare 2 fields are similar to Event Data 1 Compare 1 and Event Data 1 Compare 2 respectively.
 - Event Data 3 AND Mask field is similar to Event Data 1 AND Mask.
 - Event Data 3 Compare 1 & Event Data 3 Compare 2 fields are similar to Event Data 1 Compare 1 and Event Data 1 Compare 2 respectively.
3. Click [Save](#) to save the changes and return to event filter list.
 4. Click [Delete](#) to delete the existing filter.

6.8.2 Alert Policies

This page is used to configure the Alert Policy for the PEF configuration. You can add, delete or modify an entry in this page.

Policy Group Number	Policy Name	Description	Status
1	Alert Policy 1	Alert Policy 1 Description	Enabled
2	Alert Policy 2	Alert Policy 2 Description	Enabled
3	Alert Policy 3	Alert Policy 3 Description	Enabled
4	Alert Policy 4	Alert Policy 4 Description	Enabled
5	Alert Policy 5	Alert Policy 5 Description	Enabled
6	Alert Policy 6	Alert Policy 6 Description	Enabled
7	Alert Policy 7	Alert Policy 7 Description	Enabled
8	Alert Policy 8	Alert Policy 8 Description	Enabled
9	Alert Policy 9	Alert Policy 9 Description	Enabled
10	Alert Policy 10	Alert Policy 10 Description	Enabled
11	Alert Policy 11	Alert Policy 11 Description	Enabled
12	Alert Policy 12	Alert Policy 12 Description	Enabled
13	Alert Policy 13	Alert Policy 13 Description	Enabled
14	Alert Policy 14	Alert Policy 14 Description	Enabled
15	Alert Policy 15	Alert Policy 15 Description	Enabled
16	Alert Policy 16	Alert Policy 16 Description	Enabled
17	Alert Policy 17	Alert Policy 17 Description	Enabled
18	Alert Policy 18	Alert Policy 18 Description	Enabled
19	Alert Policy 19	Alert Policy 19 Description	Enabled
20	Alert Policy 20	Alert Policy 20 Description	Enabled
21	Alert Policy 21	Alert Policy 21 Description	Enabled
22	Alert Policy 22	Alert Policy 22 Description	Enabled
23	Alert Policy 23	Alert Policy 23 Description	Enabled
24	Alert Policy 24	Alert Policy 24 Description	Enabled
25	Alert Policy 25	Alert Policy 25 Description	Enabled
26	Alert Policy 26	Alert Policy 26 Description	Enabled
27	Alert Policy 27	Alert Policy 27 Description	Enabled
28	Alert Policy 28	Alert Policy 28 Description	Enabled
29	Alert Policy 29	Alert Policy 29 Description	Enabled
30	Alert Policy 30	Alert Policy 30 Description	Enabled
31	Alert Policy 31	Alert Policy 31 Description	Enabled
32	Alert Policy 32	Alert Policy 32 Description	Enabled
33	Alert Policy 33	Alert Policy 33 Description	Enabled
34	Alert Policy 34	Alert Policy 34 Description	Enabled
35	Alert Policy 35	Alert Policy 35 Description	Enabled
36	Alert Policy 36	Alert Policy 36 Description	Enabled
37	Alert Policy 37	Alert Policy 37 Description	Enabled
38	Alert Policy 38	Alert Policy 38 Description	Enabled
39	Alert Policy 39	Alert Policy 39 Description	Enabled
40	Alert Policy 40	Alert Policy 40 Description	Enabled

Alert Policies page

The fields of Platform Event Filter – Alert Policies section are explained below.

Policy Group Number: Displays the Policy number of the configuration.

Enable this alert: To enable or disable the policy settings.

Policy Action: To choose any one of the Policy set values (0-5) from the list.

0 - Always send alert to this destination.

1 - If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set.

2 - If alert to previous destination was successful, do not send alert to this destination. Do not process any more entries in this policy set.

3 - If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set that is to a different channel.

4 - If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set that is to a different destination type.

LAN Channel: To choose a particular channel from the available channel list.

Destination Selector: To choose a particular destination from the configured destination list.

NOTE

LAN Destination has to be configured under Settings → Platform Event Filters → LAN Destinations.

Event Specific Alert String: To specify an event-specific Alert String.

Alert String Key: To specify which string is to be sent for this Alert Policy entry.

Save: To save the Alert Policies entries.

Delete: To delete the selected configured Alert Policy.

Procedure:

1. In the Alert Policies Section, select the slot for which you have to configure the Alert policy. That is, In the Alert Policies page, if you have chosen Alert Policy Group Number as 4, you have to configure the 4th slot (the slot with Policy Number 4) in the Alert Policy Tab.
2. Select the slot and click on the empty slot to open the Alert Policies page as shown in the screenshot below.

Add Alert Policy page

3. Select **Policy Group Number** from the drop-down list.
4. Check **Enable this alert** to enable the policy settings.
5. Choose any of the Policy Action from the list.
6. Choose particular LAN Channel from the available channel list.

- In the Destination Selector, choose particular destination from the configured destination list.

NOTE

LAN Destination has to be configured under Settings → Platform Event Filters → LAN Destinations. That is if you select the number 4 for destination selector in Alert Policy Entry page, then you have to configure the 4th slot (LAN Destination Number 4) in the LAN Destinations tab.

- Enable Event Specific Alert String, if the Alert policy entry is Event Specific.
- In the Alert String Key field, choose any one value that is used to look up the Alert String to send for this Alert Policy entry.
- Click [Save](#) to save the new alert policy and return to Alert Policy list.
- Click [Delete](#) to delete a configuration.

6.8.3 LAN Destinations

This page is used to configure the LAN destination of PEF configuration. A sample screenshot of LAN Destination page is given below.

LAN Destinations

Home > Settings > Platform Event Filters > LAN Destinations

Select the LAN Channel: 1

<p>LAN Channel: 1</p> <p>LAN Destination: 1</p> <p>SNMP Trap</p> <p>Sent To:</p>	<p>LAN Channel: 1</p> <p>LAN Destination: 2</p> <p>SNMP Trap</p> <p>Sent To:</p>	<p>LAN Channel: 1</p> <p>LAN Destination: 3</p> <p>SNMP Trap</p> <p>Sent To:</p>	<p>LAN Channel: 1</p> <p>LAN Destination: 4</p> <p>SNMP Trap</p> <p>Sent To:</p>
<p>LAN Channel: 1</p> <p>LAN Destination: 5</p> <p>SNMP Trap</p> <p>Sent To:</p>	<p>LAN Channel: 1</p> <p>LAN Destination: 6</p> <p>SNMP Trap</p> <p>Sent To:</p>	<p>LAN Channel: 1</p> <p>LAN Destination: 7</p> <p>SNMP Trap</p> <p>Sent To:</p>	<p>LAN Channel: 1</p> <p>LAN Destination: 8</p> <p>SNMP Trap</p> <p>Sent To:</p>
<p>LAN Channel: 1</p> <p>LAN Destination: 9</p> <p>SNMP Trap</p> <p>Sent To:</p>	<p>LAN Channel: 1</p> <p>LAN Destination: 10</p> <p>SNMP Trap</p> <p>Sent To:</p>	<p>LAN Channel: 1</p> <p>LAN Destination: 11</p> <p>SNMP Trap</p> <p>Sent To:</p>	<p>LAN Channel: 1</p> <p>LAN Destination: 12</p> <p>SNMP Trap</p> <p>Sent To:</p>

LAN Destination page

The fields of Platform Event Filters – LAN Destinations are explained below.
Select any empty slot to configure LAN Destinations.

Select the LAN Channel: To select the LAN Channel number.

LAN Channel: Displays LAN Channel Number for the selected slot (read only).

LAN Destination: Displays ID for setting Destination Selector of Alert Policy (read only).

Destination Type: Destination type can be either an SNMP Trap or an E-mail alerts, the four fields - SNMP Destination Address, BMC User Name, Email subject and Email message needs to be filled. The SMTP server information also has to be added - under Settings → SMTP Settings. For SNMP Trap, only the SNMP Destination Address has to be filled.

SNMP Destination Address: If Destination type is SNMP Trap, then enter the IP address of the system that will receive the alert. Destination address will support the following:

- IPv4 address format.
- IPv6 address format.

BMC User Name: If Destination type is Email Alert, then choose the user to whom the email alert has to be sent. Email address for the user has to be configured under Settings → Users Management.

Email Subject & Email Message: These fields must be configured if email alert is chosen as destination type. An email will be sent to the configured email address of the user in case of any severity events with a subject specified in subject field and will contain the message field's content as the email body. These fields are not applicable for 'AMI-Format' email users.

NOTE

User should be configured under Settings → Users Management

Save: To add a new entry to the device. Alternatively, double click on a free slot.

Delete: To delete the selected configured LAN Destination.

Procedure:

1. In the LAN Destinations section, choose the number of slots to be configured. This should be the same number of slot that you have selected in the Alert Policies - Destination Selector field. That is if you have chosen the Destination Selector as 4 in the Alert Policies page of Alert Policies tab, then you have to configure the 4th slot of LAN Destination page.

2. Select the slot and click on the empty slot. This opens the LAN Destination entry.

Add LAN Destination entry page

3. In the LAN Channel Number field, the LAN Channel Number for the selected slot is displayed and this is a read only field.
4. In the LAN Destination field, the destination for the newly configured entry is displayed and this is a read only field.
5. In the Destination Type field, select the one of the types.
6. In the SNMP Destination Address field, enter the destination address.

NOTE

If Destination type is E-mail Alert, then give the e-mail address that will receive the e-mail.

7. If the destination type is Email alert, select the BMC User Name from the list of users.

NOTE

E-mail address should be configured under Settings → User Management.

8. In the Email Subject field, enter the subject.
9. In the Email Message field, enter the message.
10. Click [Save](#) to save the new LAN destination and return to LAN destination list.
11. Click [Delete](#) to delete a configuration.
12. Click [Send Test Alert](#) to send sample alert to configured destination.

NOTE

Test alert can sent only with enabled SMTP configuration. SMTP support can be enabled under Settings → SMTP Settings.

6.9 Service

This page displays the basic information about services running in the BMC. Only Administrator can modify the service.

To open Services page, click [Settings](#) → [Services](#) from the menu bar. A sample screenshot of Services page is shown below.

Service	Status	Interfaces	Secure Port	Timeout	Maximum Sessions	
web	Active	both	443	1800	20	[Edit] [Delete]
kvm	Active	both	443	1800	4	[Edit] [Delete]
cd-media	Active	both	443	N/A	1	[Edit] [Delete]
hd-media	Active	both	443	N/A	1	[Edit] [Delete]
ssh	Active	NA	22	600	N/A	[Edit] [Delete]

Service page

The fields of Services page are explained below.

Services: Displays service name of the selected slot (read-only).

Status: Displays the current status of the service, either active or inactive state.

Interfaces: It shows the interface in which service is running.

Nonsecure Port: This port is used to configure non secure port number for the service.

- Web default port is 80
- KVM default port is 7578
- CD Media default port is 5120
- HD Media default port is 5123
- Telnet default port is 23
- SOLSSH default port is 52123

NOTE

SSH service will not support non secure port. If single port feature is enabled, KVM, CD Media, FD Media and HD Media ports cannot be edited. Port value ranges from 1 to 65535.

Secure Port: Used to configure secure port number for the service.

- Web default port is 443
- KVM default port is 7582
- CD Media default port is 5124
- FD Media default port is 5126
- HD Media default port is 5127
- SSH default port is 22

NOTE

Telnet service and SOLSSH will not support secure port. If single port feature is enabled, KVM, CD Media, FD Media and HD Media ports cannot be edited. Port value ranges from 1 to 65535.

Port listening status on various feature settings:

	Single port enabled	Single port disabled	Only KVM encryption enabled	Only Media encryption enabled	Both KVM and Media encryption enabled
Adviser (video server)	7578 (LP)	7578 (EO)	7578 (LP) 7582 (EO)	7578 (EO)	7578 (LP) 7582 (EO)
Cdserver	5120 (LP)	5120 (EO)	5120 (EO)	5124 (EO)	5124 (EO)
Fdserver	5122 (LP)	5122 (EO)	5122 (EO)	5126 (EO)	5122 (LP) 5126 (EO)
Hdserver	5123 (LP)	5123 (EO)	5123 (EO)	5123 (LP) 5127 (EO)	5123 (LP) 5127 (EO)

NOTE

LP – Loopback, EO – Exposed Outside.

Timeout: Displays the session timeout value of the service. For web, SSH and telnet service, user can configure the session timeout value.


NOTE


- Web timeout value ranges from 300 to 1800 seconds.
- KVM timeout value ranges from 300 to 1800 seconds.
- SSH and Telnet timeout value ranges from 60 to 1800 seconds.
- SSH and Telnet timeout value ranges from 60 to 1800 seconds.
- SSH and Telnet service will be using the same timeout value. If you configure SSH timeout value, it will be applied to telnet service also and vice versa.
- If KVM is launched then the web session timeout will not take effect.

Maximum Sessions: Displays the maximum number of allowed sessions for the service.











Active Sessions: To view the current active sessions for the service.

To view the Active Sessions:**Procedure:**


1. Click **View** Icon () to view the details about the active sessions for the service.
2. This opens the Active Session screen (for example - Service Sessions) as shown in the screenshot below.




The screenshot shows the 'Service Sessions' page with a table of active sessions. The table has columns for Session ID, Session Type, User ID, User Name, Client IP, and Privilege. Each row also has a red 'Terminate' icon on the right.

Session ID	Session Type	User ID	User Name	Client IP	Privilege	
4	Web HTTP	2	admin	10.0.124.24	Administrator	
15	Web HTTP	2	admin	10.0.136.146	Administrator	
16	Web HTTP	2	admin	10.0.124.24	Administrator	
17	Web HTTP	2	admin	10.0.136.27	Administrator	
18	Web HTTP	2	admin	10.0.136.27	Administrator	
19	Web HTTP	2	admin	10.0.136.146	Administrator	
21	Web HTTP	2	admin	10.0.136.27	Administrator	
23	Web HTTP	2	admin	10.0.125.227	Administrator	
24	Web HTTP	2	admin	10.0.136.146	Administrator	
25*	Web HTTP	2	admin	10.0.124.24	Administrator	

Service Session page

3. **Session Type:** Displays the type of the active sessions.
4. **User:** Displays the name of the user.
5. **Client IP:** Displays the IP addresses that are already configured for the active sessions.
6. **Privilege:** Displays the access privilege of the user.
7. Select a slot and click **Terminate** icon () to terminate the particular session of the service.


To modify the existing services:**Procedure**

1. Select a slot and click **Edit** icon () to modify the configuration of the service.

NOTE

Whenever the configuration is modified, the service will be restarted automatically. User has to close the existing opened session for the service if needed.

2. This opens the Service Configuration screen as shown in the screenshot below.



Service configuration page

3. Service Name is a read only field.
4. Activate the Current State by enabling the Active check box.

NOTE

Interfaces, Nonsecure port, Secure port, Time out and Maximum Sessions will not be active unless the current state is active.

5. Choose any one of the available interfaces from the Interface Name drop-down list.
6. Enter the Nonsecure port number in the Non-secure Port field.
7. Enter the Secure Port Number in the Secure Port field.
8. Enter the timeout value in the Timeout field.

NOTE

The values in the Maximum Sessions field cannot be modified.

9. Click [Save](#) to save the entered changes else click [Cancel](#) to exit.

6.10 SMTP Settings

Simple Mail Transfer Protocol (SMTP) is an Internet standard for electronic mail (e-mail) transmission across Internet Protocol (IP) networks. You can configure the SMTP settings of the device.

To open SMTP Settings page, click [Settings](#) → [SMTP Settings](#) from the menu bar. A sample screenshot of SMTP Settings page is shown below.

SMTP Settings page

The fields of SMTP Settings page are explained below.

LAN Interface: Displays the list of LAN channels available

Sender Email ID: A valid 'Sender Address' to indicate the BMC, whenever e-mail is sent.

Primary Server Name: The 'Machine Name' of the BMC, from where the e-mail is sent.

NOTE

- Machine Name is a string of maximum 15 alpha-numeric characters.
- Space, special characters are not allowed.

Primary SMTP Support: To enable/disable SMTP support for the BMC.

Primary SMTP Port: To specify the SMTP Normal Port.

Primary Secure SMTP Port: To specify the SMTP Secure Port.

NOTE

- For Primary SMTP Port - Default Port is 25, and the Port value ranges from 1 to 65535.
- For Primary Secure SMTP Port - Default Port is 465, and the Port value ranges from 1 to 65535.

Primary Server IP: The IP address of the SMTP Server. It is a mandatory field.

NOTE

- IP Address made of 4 numbers separated by dots as in “xxx.xxx.xxx.xxx”.
- Each Number ranges from 0 to 255.
- First Number must not be 0.
- Supports IPv4 Address format and IPv6 Address format.

Primary SMTP Authentication: To enable/disable SMTP Authentication.

NOTE

SMTP Server Authentication Types supported are:

- CRAM-MD5
- LOGIN
- PLAIN

If the SMTP server does not support any one of the above authentication types, the user will get an error message stating, Authentication type is not supported by SMTP Server.

Primary Username: Enter username to access SMTP Accounts.

NOTE

- User Name can be of length 4 to 64 alpha-numeric characters, dot(.), dash(-), and underline(_).
- It must start with an alphabet.
- Other Special Charactres are not allowed.

Primary Password: Enter password for the SMTP User Account.

NOTE

- Password must be at least 4 characters long.
- White space is not allowed.
- This field will not allow more than 64 characters.

Primary SMTP STARTTLS Enable: To enable STARTTLS support for the SMTP Client.

- **Upload SMTP CA Certificate File:** File that contains the certificate of the trusted CA certs. CACERT key file should be of pem type.
- **Upload SMTP Certificate File:** Client certificate filename. CERT key file should be of pem type.
- **Upload SMTP Private Key:** Client private key filename. SMTP key file should be of pem type.

NOTE

To enable STARTTLS support, the respective SMTP support option should be enabled.

Secondary SMTP Support: It lists the Secondary SMTP Server configuration. It is an optional field. If the Primary SMTP server is not working fine, then it tries with Secondary SMTP Server configuration.

NOTE

Options of Secondary SMTP Support are same as Primary SMTP Support.

Save: To save the new SMTP server configuration.

Procedure

1. Select the LAN Interface from the drop-down list.
2. Enter the Sender Email ID in the specified field.
3. Check [Primary SMTP Support](#) option to enable SMTP support for the BMC.
4. Enter the Machine Name of the SMTP Server in the Primary Server Name.

NOTE

- Machine Name is a string of maximum 15 alpha-numeric characters.
- Space, special characters are not allowed.

5. Enter IP address of the SMTP Server in the Primary Server IP field. It is a mandatory field.
6. Enter the Primary SMTP Port in the specified field.
7. Enter the Primary Secure SMTP Port in the specified field.
8. Enable the check box [Primary SMTP Authentication](#) if you want to authenticate SMTP Server.
9. Enter your Primary User name and Primary Password in the respective fields.
10. Enable the check box [Primary SMTP SSLTLS Enable](#) to send data through secure Port.

NOTE

If this option is selected, STARTTLS option and Normal Port will be hidden.

11. Check the [Secondary SMTP Support](#) option to enable Secondary SMTP support for the BMC.
12. Enter the Secondary Server Name, Secondary Server IP, Secondary SMTP Port and Secure Port values in the respective fields.
13. Enable the check box [SMTP Server Authentication](#) if you want to authenticate SMTP Server.
14. Enter your Secondary User name and Password in the respective fields.
15. Enable the check box [Secondary SMTP SSLTLS](#) to send data through secure Port.

NOTE

If this option is selected, STARTTLS option and Normal Port will be hidden.

16. Click [Save](#) to save the entered details.

6.11 SSL Settings

The Secure Socket Layer protocol was created by Netscape to ensure secure transactions between web servers and browsers. The protocol uses a third party, a Certificate Authority (CA), to identify one end or both end of the transactions.

Configure SSL certificate into the BMC. Using this, the device can be accessed in a secured mode.

To open SSL Certificate Configuration page, click [Settings](#) → [SSL Settings](#) from the menu bar. There are three tabs in this page.

- Upload SSL Certificate option is used to upload the certificate and private key file into the BMC.
- Generate SSL Certificate option is used to generate the SSL certificate based on configuration details.
- View SSL Certificate option is used to view the uploaded SSL certificate in readable format.

6.11.1 Upload SSL Certificate

A sample screenshot of Upload SSL Certificate page is shown below.

Upload SSL Certificate page

The fields of SSL Settings – Upload SSL Settings tab are explained below.

Current Certificate: Current certificate and uploaded date/time will be displayed (read-only).

New Certificate: Certificate file should be of pem type

Current Private Key: Current Private key information will be displayed (read-only).

New Private Key: Private key file should be of pem type.

Upload: To upload the SSL certificate and privacy key into the BMC.

NOTE

After successful upload, HTTPs service will get restarted to use the newly uploaded SSL certificate.

6.11.2 Generate SSL Certificate

A sample screenshot of Generate SSL Certificate page is shown below.

Generate SSL Certificate page

The fields of SSL Settings – Generate SSL Certificate are explained below.

Common Name(CN): Common name for which certificate is to be generated.

- Maximum length of 64 characters.
- It is a string of alpha-numeric characters.
- Special characters '#' and '\$' are not allowed.

Organization(O): Organization name for which the certificate is to be generated.

- Maximum length of 64 characters.
- It is a string of alpha-numeric characters.
- Special characters '#' and '\$' are not allowed.

Organization Unit(OU): Over all organization section unit name for which certificate is to be generated.

- Maximum length of 64 characters.
- It is a string of alpha-numeric characters.
- Special characters '#' and '\$' are not allowed.

City or Locality(L): City or Locality of the organization (mandatory).

- Maximum length of 128 characters.
- It is a string of alpha-numeric characters.
- Special characters '#' and '\$' are not allowed.

State or Province(ST): State or Province of the organization (mandatory).

- Maximum length of 64 characters.
- It is a string of alpha-numeric characters.
- Special characters '#' and '\$' are not allowed.

Country(C): Country code of the organization (mandatory).

- Only two characters are allowed.
- Special characters are not allowed.

Email Address: E-mail Address of the organization (mandatory).

Valid for: Validity of the certificate.

- Value ranges from 1 to 3650 days.


Key Length: The key length bit value of the certificate.

Save: To generate the new SSL certificate.

NOTE

HTTPs service will get restarted, to use the newly generated SSL certificate.

6.11.3 View SSL Certificate



View SSL Settings page

The fields of SSL Settings – View SSL Certificate are explained below.

Basic Information: This section displays the basic information about the uploaded SSL certificate. It displays the following fields.

- Version
- Serial Number
- Signature Algorithm
- Public Key
- Issuer Common Name(CN)
- Issuer Organization(O)
- Issuer Organization Unit(OU)
- Issuer City or Locality(L)
- Issuer State or Province(ST)
- Issuer Country(C)
- Issuer E-mail Address
- Valid From
- Valid Till

Procedure

1. Click the [Upload SSL Certificate](#) tab, Browse the New Certificate and New Private key.
2. Click [Upload](#) to upload the new certificate and private key.
3. In Generate SSL Certificate, enter the following details in the respective fields.
 - The Common Name for which the certificate is to be generated.
 - The Organization for which the certificate is to be generated.
 - The Organization Unit name for which certificate to be generated.
 - The City or Locality of the organization
 - The State or Province of the organization
 - The Country of the organization
 - The Email address of the organization.
 - The number of days the certificate will be valid in the Valid For field.
4. Choose the Key Length bit value of the certificate
5. Click [Save](#) to generate the certificate.
6. Click [View SSL Certificate](#) tab to view the uploaded SSL certificate in user readable format.


NOTE

- Once you Upload/Generate the certificates, only HTTPs service will get restarted.
- You can now access your Generic MegaRAC® SP securely using the following format in your IP Address field from your Internet browser: https://<your MegaRAC® SP's IP address here>
- For example, if your MegaRAC® SP's IP address is 192.168.0.30, enter the following: https://192.168.0.30
- Please note the <s> after <http>. You must accept the certificate before you are able to access your Generic MegaRAC® SP.

6.12 System Firewall

The System Firewall page allows you to configure the firewall settings. The firewall rule can be set for an IP or range of IP Addresses or Port numbers. To view this page, you must at least be an operator. Only administrators can add or delete a firewall.

To open System Firewall page, click [Settings](#) → [System Firewall](#) from the menu bar.




Firewall Settings page

6.12.1 General Firewall Settings

Click [General Firewall Settings](#) page. The fields of Firewall Settings tab are explained below.

Existing Firewall Settings

1. Click [General Firewall Settings](#) → [Existing Firewall Settings](#) icon. A blank page will be opened if you did not add anything in “Add Firewall settings”. A sample screenshot of Existing Firewall Settings page is shown below.



Existing Firewall Settings page

2. **Block All:** The blocked incoming IP's and Port's can be viewed.
3. **Flush All:** To flush all the system firewall rules (Read-Only).
4. Select **Timeout** to enable or disable firewall rules with timeout.
5. **Start Date:** The respective firewall rule effect will start from this date.
6. **Start Time:** The respective firewall rule effect will start from this time.
7. **End Date:** The respective firewall rule effect will end from this date.
8. **End Time:** The respective firewall rule effect will end from this time.

Add Firewall Settings

1. Click [General Firewall Settings](#) → [Add Firewall Settings](#). This opens the Existing Firewall Settings page as shown below.

Add Firewall Settings page

2. Select [Block All](#) to block all the incoming IP's and Port's.
3. Select [Flush All](#) to flush all the system firewall rules.
4. Select [Timeout](#) to enable or disable firewall rules with timeout.
5. Enter [Start Time](#) to start the respective firewall rule effect from this time.
6. Enter [End Time](#) to end the respective firewall rule effect from this time.

NOTE

The time should be in the dd-mm-yy:hh-mm format.

7. Click [Save](#) to save the changes made else click [Cancel](#) to go back to the previous screen.


IP Address Firewall Rules

To View Existing IP Rules or a range of IP Addresses,

A blank page will be opened if you did not add anything in “Add IP Rule”.

Procedure to Add IP Rule

1. Click [Settings](#) → [System Firewall](#) → [IP Address Firewall Rules](#) → [Existing IP Rules](#). A blank page will be opened if you did not add anything in “Add IP Rule”. If any rule is added, then the added rule will be listed in “Existing IP Rules” page.
2. Click the [IP Addresses](#) tab. A sample screenshot of IP Addresses tab is shown below.



Existing Rule IP page

IP Single (or) Range Start: To show the configured Port Address or Range of Ports.

IP Range End: To show the configured Port Address or Range of Ports.

Enable Timeout: To enable/disable Timeout.

Start Date: The respective firewall rule effect will start from this date.

Start Time: The respective firewall rule effect will start from this time.

End Date: The respective firewall rule effect will end from this date.

End Time: The respective firewall rule effect will end from this time.

Rule: To indicate the current setting of the listed Port or Range of Port rules (Allow or Block) status.

Delete: To delete the selected slot.

Procedure To add an IP address or range of IP addresses,

1. Click [Settings](#) → [System Firewall](#) → [IP Address Firewall Rules](#) → [Add New IP Rule](#) to add a new IP or range of IP address.

Add IP Rule page

2. In the Add new rule for IP page, Enter the IP address and a range of IP addresses in the IP Single or IP Range Start field.

NOTE

- IP Address will support IPv4 Address format only:
 - IPv4 Address made of 4 numbers separated by dots as in xxx.xxx.xxx.xxx.
 - Each number ranges from 0 to 255.
 - First number must not be 0.
 - IPv6 Address made of 8 groups of 4 Hexadecimal digits separated by colon as in xxx x:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx.

3. Enter IP range end value in the IP Range End field.
4. Enable [Timeout](#) to enable firewall rules with timeout.
5. Enter [Start Date](#) to start the respective firewall rule effect from this date.
6. Enter [End Date](#) to end the respective firewall rule effect from this date.
7. Enter [Start Time](#) to start the respective firewall rule effect from this time.
8. Enter [End Time](#) to end the respective firewall rule effect from this time.

NOTE


The date and time should be in the YYYY/MM/DD and hh-mm format respectively.

9. Determine the rule to block or accept.
10. Click [Save](#) to save the changes made.

Port Firewall Rules

To view Existing Port Rules

1. Click [Settings](#) → [System Firewall](#) → [Port Firewall Rules](#) → [Existing Port Rules](#). A blank page will be opened if you did not add anything in “Add New port Rule”. If any rule is added, then the added rule will be listed in “Existing Port Rules” page.
2. Click the [Existing Port Rules](#). A sample screenshot of Port tab is shown below.



Existing Port Rules page

6.12.2 System Firewall

The fields of System Firewall: Existing Port Rules page are explained below.

Port Single (or) Range Start: To configure the Port or Range of Port Addresses.

Port Range End: To configure the Port or Range of Port Addresses.

Protocol: This field specifies the protocols for the configured Port or Port Ranges.

Network Type: This field specifies the affected network type for the particular Port or Port Ranges.

Enable Timeout: To enable or disable firewall rules with timeout.

Start Date: The respective firewall rule effect will start from this time.

Start Time: The respective firewall rule will start from this time.

End Date: The respective firewall rule effect will end on this date.

End Time: The respective firewall rule will end at this time.

Rule: To indicate Allow or Block status.

Delete: To delete the entry to the firewall rules list.

Procedure

To Add Port/Range of ports

1. To add a new rage of Port address, click the [Add](#) button.

Add Port Rule page

2. In the Add new rule for Port window, Enter the port number or a range of port numbers in the Port Single (or) Range Start field.

NOTE

Port value ranges from 1 to 65535.

3. Enter the end value in the Port Range End field.
4. Select the Protocol to be either [TCP](#) or [UDP](#) or [Both](#).
5. Select the Network Type. It may be [IPv4](#) or [IPv6](#) or [Both](#).
6. Select [Timeout](#) to enable or disable firewall rules with timeout.
7. Enter [Start Time](#) to start the respective firewall rule effect from this time.
8. Enter [Start Date](#) to start the respective firewall rule effect from this date.
9. Enter [End Date](#) to end the respective firewall rule effect on this date.
10. Enter [End Time](#) to end the respective firewall rule effect at this time.

NOTE


The time should be in the YYYY/MM/DD:hh-mm format.

11. Select the Rule to determine the rule to [Block](#) or [Allow](#).
12. Click [Save](#) to save the changes made.


6.13 User Management

The User Management page allows you to view the current list of user slots for the server. You can add a new user and modify or delete the existing users.

To open User Management page, click [Settings](#) → [User Management](#) from the menu bar. A sample screenshot of User Management page is shown below.



User Management page

Click [user](#) icon () and select any free slot to add a new user from the User Management main page. Click [Delete](#) icon (x) on the top right corner to directly delete an item from the list.

NOTE

The Free slots are shown as “Disabled” in all columns for the slot.

The fields of User Management page are explained below.

User ID: Displays the ID number of the user.

NOTE

The list contains a maximum of ten users only.

User Name: Displays the name of the user.

User Access: To enable or disable the access privilege of the user.

Network Privilege: Displays the network access privilege of the user.

SNMP Status: Displays if the SNMP status for the user is enabled or Disabled.

E-mail ID: Displays e-mail address of the user.

Add User: To add a new user.

Delete User: To delete an existing user.

Procedure to add a new User

1. To add a new user, select a free section and click on the empty section. This opens the Add User screen as shown in the screenshot below.

User Management Configuration page

2. Enter the name of the user in the User Name field.

NOTE

- User Name is a string of 1 to 16 alpha-numeric characters.
- It must start with an alphabetical character.
- It is case-sensitive.
- Special characters '-'(hyphen), '_'(underscore), '@'(at sign) are allowed.
- For 20 Bytes password, LAN session will not be established.

3. Set Password Size for the new password.
4. In the Password and Confirm Password fields, enter and confirm your new password.

NOTE

- Password should be the combination of alphabets, numbers, symbol and upper case characters.
- White space is not allowed.
- This field will not allow more than 16/20 characters based on Password size field value.
- This field will not allow the below mentioned characters.

5. Enable or Disable the Enable User Access Privilege.

NOTE

- Enabling Channel User Access will intern assign the IPMI messaging privilege to the specific Channel user.
- It is recommended that the IPMI messaging option should be enabled for the user to enable the User Access option, While creating User through IPMI.

6. In the Network Privilege and Serial Privilege fields, select the privileges assigned to the user which could be Administrator, Operator, User, OEM or None

7. Check KVM Access to assign the KVM privilege for the user.

8. Check VMedia Access assign the VMedia privilege for the user.

NOTE

It is recommended that the privileges support to KVM and VMedia should be provided only to the ADMIN user and shouldn't be provided to USER and OPERATOR privilege level users. The Admin user can provide the privilege support to USER and OPERATOR privilege level users at their own risk

9. Check the [SNMP Access](#) check box to enable SNMP access for the user.

NOTE

Password field is mandatory, if SNMP Status is enabled.

10. Choose the [SNMP Access level](#) option for user from the SNMP Access level (SHA or MD5) drop-down list. Either it can be Read Only or Read Write.

11. Choose the [SNMP Authentication Protocol](#) (SHA or MD5) to use for SNMP settings from the drop down list.

NOTE

Password field is mandatory, if Authentication protocol is changed.

12. Choose the [Encryption algorithm](#) to use for SNMP settings from the SNMP Privacy protocol (AES or DES) drop-down list.

13. In the Email ID field, enter the email ID of the user. If the user forgets the password, the new password will be mailed to the configured email address.

NOTE

SMTP Server must be configured to send emails.

- **Email Format:** Two types of formats are available:
- **AMI-Format:** The subject of this mail format is 'Alert from (your Host name)'. The mail content shows sensor information, ex: Sensor type and Description.
- **Fixed-Subject Format:** This format displays the message according to user's setting. You must set the subject and message for email alert.

14. In the Upload SSH Key field, click [Browse](#) and select the [SSH key file](#).


NOTE

SSH key file should be of pub type.

15. Click [Save](#) to save the new user and return to the users list.

To Modify User

1. To modify the existing user, click on the [active user](#) tab. This opens a User screen as shown in the screenshot below.




User Management Configuration page

2. Check [Change Password](#), if you wish to change the existing Password.
3. Follow the steps (3 to 15) of Procedure to add a new User.
4. Click [Save](#) to save the changes and return to the users list.
5. Click [Delete](#) to delete the user.

6.14 Video Recording

The Video Recording consists of the following. A sample screenshot of the Video Recording is given below.



Video Recording page


- Auto Video Settings
 - Video Trigger Settings
 - Video Remote Storage
 - Pre-Event Video Recordings
- SOL Settings
 - SOL Trigger Settings
 - SOL Video Remote Storage
 - SOL Recorded Video
 - Java SOL

A detailed description of the menu items are given below.

6.14.1 Auto Video Settings

This page is used to configure the events that will trigger auto video recording function of the KVM server.

A sample screenshot of Auto Video Settings is shown below.



Auto Video Settings page

Video Trigger Settings

To triggers for Auto Video Recording, click [Video Recording](#) → [Auto Video Settings](#) → [Video Trigger Settings](#) from the menu bar. A sample screenshot of Video Trigger Settings page is shown below.

Video Trigger Settings page

Event List: It shows the list of available events to be configured. The events are mentioned below.

- Critical Events (Temperature/Voltage)
- Non Critical Events (Temperature/Voltage)
- Non Recoverable Events (Temperature/Voltage)
- Fan state changed Events
- Watchdog Timer Events
- Chassis Power on Events
- Chassis Power off Events
- Chassis Reset Events
- LPC Reset Events
- Date and Time Event
- Pre-Event Video Recording
 - Pre-crash
 - Pre-reset

Save: To save any changes made.


Procedure:

1. Check the events to be enabled.
2. To set particular Date and Time Event, check the option [Date and Time Event](#).
 - a. Choose the month, day and year from the Date field
 - b. Enter/Choose the Time in hh:mm format in the respective fields.

NOTE

KVM service should be enabled to perform auto-video recording. The date and time should be in advance to the system date and time.

3. Click [Pre-Event Video Recording](#) to edit the Pre-Event video recording configurations. A sample screenshot of Pre-Event Video Recordings page is shown as below.



Pre-Event Video Recording page

- a. To set video quality, select ranges (very low, low, high, average and normal) from Video Quality drop-down list.
 - b. To set compression mode, select modes (high, normal, low, no) from Compression Mode drop-down list.
 - c. To set number of frames per second, select frames/sec (1-4) from Frames Per Second drop-down list.
 - d. To set duration of video, select second (10-60) from Video Duration drop-down list.
 - e. Click [Save](#) to save the changes made on the Pre-Event Video Recording.
4. Select [Crash Reset](#) either [Pre-crash](#) or [Pre-reset](#).
 5. Click [Save](#) to save the changes.

Video Remote Storage

To Video Remote Storage capture host video before critical event like crash or reset occurs, click [Video Recording](#) → [Auto Video Settings](#) → [Video Remote Storage](#). A Sample screenshot of Video Remote Storage is as shown below.

Video Remote Storage page

1. Check [Record Video to Remote Server](#) to enable the Remote Video Support.

NOTE

By default, video files will be stored in local path of BMC. If remote video support is enabled, then the video files will be stored only in remote path, not within BMC.

2. Enter Maximum Duration (Sec) of the video.
3. Enter Maximum Size (MB) of the video.
4. Enter Maximum Dumps of the video.

NOTE

The Maximum Duration of the video should be in the range from 1 to 3600 seconds. The Maximum Size of the video should be in the range from 1 to 500 mb. The Maximum Dumps should be in the range from 1 to 100. The recorded video file should meet either the size constraint or duration constraint, according to the configured settings, depending on which constraint is met first.

5. Enter the Server Address.

NOTE

Server address will support the following:

- IP Address (Both IPv4 and IPv6 format).
- FQDN (Fully qualified domain name) format.

6. Enter the source path in Path in Server field.

7. Select the Share Type (NFS/CIFS). If the selected share type is (CIFS), Enter the User Name, Password and Domain Name in the respective fields.

8. Click [Save](#) to save the settings.

Pre-Event

Pre-Event video recording files will be named as per event captured. For example - if any video is recorded for Crash Event, the recorded file will be named as pre_crash_video_x.dat, where x is file count, similarly if it is recorded for reset event it will be named as pre_reset_video_x.dat.

Post-Event

Post-Event video recording files will be named as shown below.


video_dump_<Hostname>_%Y%m%dT%H%M%S.dat.

File Count and Duration for Pre and Post Event Recordings are as shown in the below table:

	Auto Video Recording (Post Event)	Pre-Event Video Recording(only for Crash/reset event)
Time Limits	20 seconds or 5.5MB video allowed if Local Storage.	Default-10sec, but can be configurable up to 60sec.
	300 seconds recording allowed if Remote Storage(Remote Path).	
Video File Count	Local Storage: 2 (After 2, if video recording starts, the oldest video file among the two files will be replaced with the new video)	1 if local storage/3 if remote storage. (Once Max file count reached, will Delete Old video file to store new file.)
	Remote Storage: maximum configured dump value of video files for Remote Storage.	

SOL Settings

To open SOL Set page, click [Settings](#) → [Video Recording](#) → [SOL Settings](#) from the menu bar. A sample screenshot of SOL Settings page is shown below.



SOL Settings page

The SOL Settings consists of four fields.

- SOL Trigger Settings
- SOL Video Remote Storage
- SOL Recorded Video
- Java SOL

SOL Trigger Settings

Event List: It shows the list of available events to be configured. The events are mentioned below.

- Critical Events (Temperature/Voltage)
- Non Critical Events (Temperature/Voltage)
- Non Recoverable Events (Temperature/Voltage)
- Fan state changed Events
- Watchdog Timer Events
- Chassis Power on Event
- Chassis Power off Event
- Chassis Reset Events
- Date and Time Events
- LPC Reset Events

Save: To save any changes made.

A sample screenshot of SOL Trigger Settings page is shown as below.

SOL Trigger Settings page

Procedur:

1. Check the events to be enabled to configure which event on the page will trigger the SOL video recording option to start.
2. To set particular Date and Time Event, check the option Date and Time Event.
 - a. Choose the month, day and year from the Date field.
 - b. Enter the Time in hh:mm:ss format in the respective fields.

NOTE

The date and time should be in advance to the system date and time.

3. Click Save to save the changes.

SOL Video Remote Storage

This page allows you to configure recorded video files. The sample screenshot and various fields of SOL Video Remote Storage are given below.

SOL Video Remote Storage page

Procedure for SOL Video Remote Storage:

1. Click [SOL Video Remote Storage](#).
2. Enter Log Size (KB). The value will support maximum length of 10 digits.
3. Enter Log File Count. The default number of Log files count ranges from 1 to 10.
4. Check Record Video to Remote Server to enable the Remote Video Support.

NOTE

The Server Address, Source Path and Share Type will be enabled only if the Video Support option is enabled.

5. Enter the Server Address.

NOTE

Server address will support the following:


- IP Address (Both IPv4 and IPv6 format).
- FQDN (Fully qualified domain name) format.

6. Enter the source path in Path in server filed.

7. Select the Share Type(NFS/CIFS). If the selected share type is CIFS, Enter the User Name, Password and Domain Name in the respective fields.
8. Click [Save](#) to save the settings.

SOL Recorded Video

This page displays the list of available recorded video files. The sample screenshot and various fields of SOL Recorded Video are given below.



The screenshot shows a web page titled "Sol Recorded video". The breadcrumb navigation is "Home > Settings > video > Sol > Sol Recorded video". There is a green question mark icon in the top right corner. Below the header is a table with three columns: "S.No", "File Name", and "File Information".

S.No	File Name	File Information
------	-----------	------------------

SOL Recorded Video page

#: The serial number

File Name: The video filename

File Information: Day, date and time of video upload

Download: To download the selected video

Delete: To delete the selected video.

NOTE

The timestamp displayed in the file information represents last modified time, and it will be updated (if the file is modified) when the webpage is refreshed.


Procedure

1. Select a video and click the [Download](#) button to download and save the video.
2. Click the [Delete](#) button to delete the selected video.

Java SOL

This page allows you to launch the Java SOL. The Java SOL is used to view the host screen using the SOL Redirection.

To open Java SOL page, click [Settings](#) → [Video Recording](#) → [SOL Settings](#) → [Java SOL](#) from the menu bar. A sample screenshot of Java SOL page is shown below.




Java SOL page

1. Click [Download Java SOL](#) to download JNLP File.
2. A pop-up window prompts you to choose Open with/Save File, choose the required option.
3. Click [OK](#) to download JNLP File else click [Cancel](#) to exit. For more details on SOL, click SOL.

6.15 Web Instances

This page allows you to provide the number of back end web server instances that would be launched to provide load balancing.

To open Web Server Instances Settings page, click [Settings](#) → [Web Server Instances](#) from the menu bar. A sample screenshot of Web Server Instances page is shown below.



Web Server Instances page

The fields of Web Server Instances are explained below.

Number of Concurrent Web Server Instances: To specify the number of backend web server instances that would be launched to provide load balancing.

Save: To save the settings.

Procedure

1. Enter the number of backend web server instances in the Number of Concurrent Web Server Instances field.
2. Click Save button to save the entries.

Chapter 7. Remote Control

To open Remote Control page, click [Remote Control](#) from the menu bar. A sample screenshot of the Remote Control page is shown below.




Remote Control page

A detailed description of the menu items are given below.

7.1 KVM

Open the Remote Control page, click [Launch KVM](#). A sample screenshot of the Remote KVM page is shown below.



Remote KVM page

Click [Launch KVM](#) to open the Remote Control KVM page.

Start KVM: Starts the H5Viewer video redirection.

Stop KVM: Stops the H5Viewer video redirection.

Video Record: This menu contains the following sub menu items

Record Video: This option is to start recording the screen. Stop

Recording: This option is used to stop the recording.

Record Settings: This option is used to set Video Recording Duration.

Send Keys: This option is used to key items. This menu contains the following sub menu items.

- Hold Down
- Press and Release

Hold Down

This menu contains the following sub menu items.

Right Ctrl Key: This menu item can be used to act as the right-side <CTRL> key when in Console Redirection.

Right Alt Key: This menu item can be used to act as the right-side <ALT> key when in Console Redirection.

Right Windows Key: This menu item can be used to act as the right-side <WIN> key when in Console Redirection.

Left Ctrl Key: This menu item can be used to act as the left-side <CTRL> key when in Console Redirection.

Left Alt Key: This menu item can be used to act as the left-side <ALT> key when in Console Redirection.

Left Windows Key: This menu item can be used to act as the left-side <WIN> key when in Console Redirection. You can also decide how the key should be pressed: Hold Down or Press and Release.

Press and Release

Ctrl+Alt+Del: This menu item can be used to act as if you depressed the <CTRL>, <ALT> and keys down simultaneously on the server that you are redirecting.

Left Windows Key: This menu item can be used to act as the left-side <WIN> key when in Console Redirection. You can also decide how the key should be pressed: Hold Down or Press and Release.

Right Windows Key: This menu item can be used to act as the right-side <WIN> key when in Console Redirection.

Context Menu Key: This menu item can be used to act as the context menu key, when in Console Redirection.

Print Screen Key: This menu item can be used to act as the print screen key, when in Console Redirection.

Hot Keys: This menu is used to add the user configurable shortcut keys to invoke in the host machine. The configured key events are saved in the BMC.

This menu contains the following sub menu items.

- **Add Hot Keys** - This menu is used to enable macros. Click [Add](#) to macros.


Browse File: Used to select the CD image file to be redirected to the host.

Start Media: Redirects the selected CD image file to the host.

Stop Media: Stops the CD media redirected to the host.


Procedure To Start KVM

1. Click [Start KVM](#) to start the H5Viewer video redirection. A sample screenshot is as shown below.



Start KVM page

2. Click [Browse](#) to select CD Image.
3. Click [Start Media](#) to redirect the selected CD image file to the Host. A sample screenshot is as shown below.



Start Media page

4. To stop the recording, click [Stop Record](#).

Keyboard Layout

List of Host Physical Keyboard languages supported in SPX H5Viewer.

1. English U.S.
2. German
3. Japanese

Video Record

This menu contains the following sub menu items.

Pause Video: This option is used to resume the Console Redirection when the session is paused.

Resume Video: This option is used to resume the Console Redirection when the session is paused.

Refresh Video: This option can be used to update the display shown in Console Redirection window.

Host Display

Display on: If you disable this option, the display will be shown on the screen in Console Redirection.

Display off: If you enable this option, the server display will be blank but you can view the screen in Console Redirection. If you disable this option, the display will be back in the server screen.

Capture Screen: This option helps to take the screenshot of the host screen and save it in the client's system.

Mouse

Show Client Cursor: This menu item can be used to show or hide the local mouse cursor on the remote client system.

Mouse Mode: This option handles mouse emulation from local window to remote screen using either of the two methods. Only 'Administrator' has the right to configure this option.

- **Absolute mouse mode:** The absolute position of the local mouse is sent to the server if this option is selected.
- **Relative mouse mode:** The Relative mode sends the calculated relative mouse position displacement to the server if this option is selected.
- **Other mouse mode:** This mousemode sets the client cursor in the middle of the client system and will send the deviation to the host. This mousemode is specific for SUSE Linux installation.

NOTE

Client cursor will be hidden always. If you want to enable, use Alt + C to access the menu.

Options

The Bandwidth Usage option allows you to adjust the bandwidth. You can select one of the following options.

Block Privilege Request: To enable or disable the access privilege of the user.

Keyboard/Mouse Encryption: This option allows you to encrypt keyboard inputs and mouse movements sent between the connections.

Power

The power options are to perform any power cycle operation. Click on the required option to perform the following operation.

Power Reset: To reboot the system without powering off (warm boot).

Power On: To power on the server.

Power Cycle: To first power off, and then reboot the system (cold boot).

Active Users

Click this option to displays the active users and their system ip address.


7.2 SOL

Click [Active](#) to open the Remote Control SOL page.



Remote Control SOL page

Click [SOL Page](#) and press any Key.



Chapter 8. Images Redirection

This page is used to configure the images into BMC for redirection. This can be done either by uploading an image into BMC say, Local Media or by mounting the image from the remote system, Remote Media.

To open Images Redirection page, click [Images Redirection](#) from the menu bar. A sample screenshot of Images Redirection page is shown below.



Image Redirection page

The fields of Images Redirection images page are explained below.

- Remote Images

8.1 Remote Image

The displayed table shows configured images on BMC. You can configure images of the remote media server.

Media Type	Media Instance	Image Name	Status	Session Index
CD/DVD	0	ubuntu-14.04.3-desktop-i386.iso	Halted	N/A
CD/DVD	1	ubuntu-14.04.3-desktop-i386.iso	Halted	N/A
CD/DVD	2	ubuntu-14.04.3-desktop-i386.iso	Halted	N/A
CD/DVD	3	ubuntu-14.04.3-desktop-i386.iso	Halted	N/A
Floppy	0	fdboot2.img	Halted	N/A
Floppy	1	fdboot2.img	Halted	N/A
Floppy	2	fdboot2.img	Halted	N/A
Floppy	3	fdboot2.img	Halted	N/A
Hard disk	0	fdboot2.img	Halted	N/A
Hard disk	1	fdboot2.img	Halted	N/A
Hard disk	2	fdboot2.img	Halted	N/A
Hard disk	3	fdboot2.img	Halted	N/A

Remote Media page

NOTE

More than one image can be configured for each image type. At maximum 4 images can be configurable.

- To configure the image, You need to enable Remote Media support under Settings → Media Redirection → General Settings.
- To start/stop redirection and to delete an image, you must have Administrator Privileges.
- Free slots are denoted by “~”.

The fields of Remote Media tab are as follows:

Media Type: Displays type of Media such as CD/DVD, Floppy, Harddisk and All.

Media Instance: Displays total media instance count.

Image Name: Displays the default recovery image name on the server.

Status: Displays the status of the media.

Session Index: Displays Media Server Session Index.

Start/Stop Redirection: To start or stop Media redirection.


Pause: To Pause the Media redirection.

Procedure:

1. To Start/Stop Redirection and configure Remote media images, click  (Start/Stop icon) and make sure Remote Media Support option is enabled.

NOTE

The Start Redirection button is active only for VMedia enabled users.

2. Select a configured slot and click  (Start/Stop icon) to start the Remote media redirection. It is a toggle button, if the image is successfully redirected, then click (Start/Stop icon) to stop the Remote media redirection.


NOTE

Redirection needs to be stopped to clear the image.

Chapter 9. Power Control

This page allows you to view and control the power of your server.

To open Power Control, click [Power Control](#) from the menu bar. A sample screenshot of Power Control is shown below.



Power Control page

The various options of Power Control are given below.

Power Off: To immediately power off the server.

Power On: To power on the server.

Power Cycle: This option will first power off, and then reboot the system (cold boot).

Hard Reset: This option will reboot the system without powering off (warm boot).

ACPI Shutdown: This option to initiate operating system shutdown prior to the shutdown.

Perform Action: Click this option to perform the selected operation.

Procedure

Select an action and click [Perform Action](#) to proceed with the selected action.

NOTE

During Execution you will be asked to confirm your choice. Upon confirmation, you will be informed about the status after few minutes.

Chapter 10. Maintenance Group

This group of pages allows you to do maintenance tasks on the device. The menu contains the following items:


- Backup Configuration
- Firmware Image Location
- Firmware Information
- Firmware Update
- Preserve Configuration
- Restore Configuration
- Restore Factory Defaults
- System Administrator

A detailed description is given below.

10.1 Backup Configuration

This page allows you to select the specific configuration items to be backup in case of “Backup Configuration”.

To open Backup Configuration page, click [Maintenance](#) → [Backup Configuration](#) from the menu bar. A sample screenshot of Backup Configuration page is shown below.



Backup Configuration page

The various fields of Backup Configuration page are given below.

Check All: To select all the configuration list.

Download Config: To download and save the configuration files backup from BMC to client system.

Procedure for Backup Configuration:

1. Click [Check All](#) to backup all the configuration items. The Backup Configuration page will appear as shown in the above screenshot.
2. Click [Download Config](#) to save the backup file to the client system.
3. Click [OK](#) to perform the backup action. The Backup file will be saved in the client system.
4. Click [Cancel](#) to cancel the backup process.

10.2 Firmware Image Location

This page is used to configure firmware image into the BMC.

To open Firmware Image Location, click [Maintenance](#) → [Firmware Image Location](#) from the menu bar. A sample screenshot of Firmware Image Location page is shown below.

Firmware Image Location page

The various options of Image Transfer Protocol are given below.

Image Location Type: Type of location to transfer the firmware image into the BMC either Web Upload during Flash or TFTP Server.

TFTP Server Address: Address of the server where the firmware image is stored.

NOTE

The Server supports both IPv4 and IPv6 addresses

- IP Address made of 4 numbers separated by dots as in “xxx.xxx.xxx.xxx”.
- Each number ranges from 0 to 255.
- First number must not be 0.
- IPv6 Address made of 8 groups of 4 Hexadecimal digits separated by colon as in “xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx:xxxx”.
- Hexadecimal digits are expressed as lower-case letters.

TFTP Image Name: Full Source path with file name of the firmware image is stored on TFTP Server.

TFTP Retry Count: Number of times to be retried in case a transfer failure occurs. Retry count ranges from 0 to 255.

Save: To save the configured settings.


Procedure

1. Select the Image Location Type (Web Upload during flash/ TFTP Server).
2. If the protocol selected is TFTP, enter the IP address of the server in the TFTP Server Address field.
3. Enter the TFTP Image Name in the given field.
4. Enter the TFTP Retry Count value.
5. Click [Save](#) to save the changes.

10.3 Firmware Information

This page is used to configure the Firmware Information settings.

To open System Administrator page, click [Maintenance](#) → [Firmware Information](#) from the menu bar. A sample screenshot of Firmware Information page is shown below.



Firmware Information

The various fields of Firmware Information page are given below.

Active Firmware

Build Date: Describes the Build Date of the active BMC image.

Build Time: Describes the Build Time of the active BMC image.

Firmware version: Describes the Firmware version of the active BMC image.

BIOS Firmware version: Describes the BIOS Firmware version of the node.

10.4 Firmware Update

This wizard takes you through the process of firmware upgradation. A reset of the box will automatically follow if the upgrade is completed or cancelled. An option to Preserve All Configuration is available. Enable it, if you wish to preserve configured settings through the upgrade.

Warning: Please note that after entering update mode widgets, other web pages and services will not work. All open widgets will be closed automatically. If upgrade process is cancelled in the middle of the wizard, the device will be reset.

NOTE

The firmware upgrade process is a crucial operation. Make sure that the chances of a power or connectivity loss are minimal when performing this operation.

Once you enter into Update Mode and choose to cancel the firmware flash operation, the Mega-RAC® card must be reset. This means that you must close the Internet browser and log back onto the MegaRAC® card before you can perform any other types of operations.

Once Firmware upgrade using web is started, the regular IPMI command will not be allowed for safety concern if Enable IPMI Command handling during flashing support is disabled in project configuration.

To configure, choose [Firmware Image Location](#) under Maintenance. To open Firmware Update page, click [Maintenance](#) → [Firmware Update](#) from the menu bar.

The protocol information to be used for firmware image transfer during this update is as follows. To configure, choose 'Firmware Image Location' under Maintenance.

Protocol Type: HTTP/HTTPS

Preserve all Configuration. This will preserve all the configuration settings during the firmware update - irrespective of the individual items marked as preserve/overwrite in the table below.

All configuration items below will be preserved as default during the restore configuration operation. Click "Edit Preserve Configuration" to modify the Preserve status settings.

[Edit Preserve Configuration](#)

S.No	Preserve Configuration Item	Preserve Status
1	SDR	Overwrite
2	FRU	Overwrite
3	SEL	Overwrite
4	IPMI	Overwrite
5	NETWORK	Overwrite
6	NTP	Overwrite
7	SSH	Overwrite
8	KVM	Overwrite
9	AUTHENTICATION	Overwrite
10	SYSLOG	Overwrite

Select Firmware Image

No file selected.

Firmware Update page

The various fields of Firmware Update are as follows.

- Preserve all Configuration: To preserve all configuration.
- Edit Preserve Configuration: To modify the Preserve status settings.
- Select Firmware Image: To Select the Firmware image to be uploaded.
- Start Firmware Update: To Start the Firmware Update.

This wizard takes you through the process of AMI based firmware upgradation. The protocol information to be used for firmware image transfer during this update is as follows.

NOTE

All configuration items will be preserved/overwrite as default during the restore configuration operation.


Procedure

1. Click Preserve all Configuration to preserve all configuration.
2. Click Browse to select firmware image. The Firmware update undergoes the following steps:
 - a. Closing all active client requests
 - b. Preparing Device for Firmware Upgrade
 - c. Uploading Firmware Image

NOTE

A file upload pop-up will be displayed for http/https but in the case of tftp files, the file is automatically uploaded displaying the status of upload.

- d. Browse and select the Firmware image to flash and click Upload.
- e. Click Start firmware update start the Firmware Update. A warning message will be prompted you to proceed further.
- f. Click OK to start the Firmware Update. The sample screenshot is shown below.



Firmware Update page - Image Upload

g. Verifying Firmware Image

In Section Based Firmware Update, you can configure the firmware image for section based flashing. Check the required sections and click Proceed to update the firmware.

If flashing is required for all images, select the option Full Flash .


If you select Version Compare Flash option from web, the current and uploaded module versions, FMHlocation, size will be compared.

If the modules differ in size and location, proceed with force firmware upgrade. If all the module versions are same, restart BMC by saying all the module versions are similar.

If only few module versions are differ, those module will be flashed.

NOTE

Only selected sections of the firmware will be updated. Other sections are skipped. Before starting flash operation, you are advised to verify the compatibility between image sections.




Section Based Firmware Flashing

10.5 Preserve Configuration

This page allows the user to configure the preserve configuration items, which will be used by the Restore factory defaults to preserve the existing configuration without overwriting with defaults/ Firmware Upgrade configuration.

To open Preserve Configuration page, click [Maintenance](#) → [Preserve Configuration](#) from the menu bar. A sample screenshot of Preserve Configuration page is shown below.



Preserve Configuration page

The various fields of Preserve Configuration are as follows.

Click here to go to Firmware Update or Restore Configuration: This link will redirect to the Firmware Update or Restore Configuration page which needs to be preserved.

Check All: To check the entire configuration list.

Save: To save any changes made.

NOTE

This configuration is used by Restore Factory Defaults process.

Files Preserved

SDR

Following files will be preserved.

SDR.dat: This file contains the sensor data record information that is used in IPMI.

[Dependency Configurations - NIL](#)

FRU

Following files will be preserved.

FRU.bin: This file contains the logical field replaceable unit data that are used by IPMI

[Dependency Configurations - SDR](#)

SEL

Following files will be preserved when Delete SEL reclaim space is disabled. SEL.dat: This file contains the system event logs that are being logged by the IPMI. Following files will be preserved when Delete SEL reclaim space is enabled.

SEL.dat: This file contains the system event logs that are being logged by the IPMI. Following files will be preserved when Delete SEL reclaim space is enabled.

Selreclaiminfo.ini – The file contains the SEL repository information.

SEL folder – This folder contains the multiple files of event logs.

[Dependency Configurations – IPMI](#)

IPMI

The following files are preserved in IPMI configuration.

IPMI.conf: This file contains the IPMI configurations such as SEL rep size, SDR rep size, interface specific, enable/disable, Primary/Secondary, IPMB Bus number etc.

dcmi.conf: This file contains the DCMI1.5 specification parameters such as DHCP Timing1, DHCP Timing2, DHCP Timing3. The files are preserved only when DCMI1.5 feature is enabled in the MDS project configuration.

pwdEncKey: This file contains the keys that are used to decrypt the passwords. When the user password option is enabled in the MDS project configuration, this file will be preserved.

[Dependency Configurations - NIL](#)

Network

To save network settings related with IPMI (LAN IP or DHCP configuration), selecting “IPMI” will automatically select the another option “Network” and it’s vice versa. After restore configuration, the Network Configuration will be preserved successfully. Following files will also be preserved.

dhcp.conf: This file is to configure the host name in the FQDN format.

dns.conf: This file is used to configure the DNS registration method and DNS server for the particular interface.

hostname: This file is used to store the Hostname of the BMC.

hostname.conf: This file is used to configure the host name creation method Manual/Automatic for the BMC.

Vlaninterfaces: This file helps to enable the vlan interface for the particular LAN interface

vlansetting.conf: This file is to store the vlan ID and Vlan priority for the particular VLAN interface entry.

bond.conf: This file is to enable the bond interface for the specified LAN interfaces.

Interfaces: This file is to configure the IP/IPV6 addresses for the LAN interface using static/DHCP method.

activeslave.conf: This file is to configure the active interface for the specified bond interface. This file depends on bond.conf.

hosts: This file is used to store the host name to map the IP address.

hosts.allow: This file contains the list of hosts that has permission to access the system.

hosts.deny: This file contains the list of host that does not allow accessing the system.

resolv.conf: This file is used to store the nameserver and domain name for hostname registration.

dhcp6c-script: This file is used to configure the domain name, DNS server IPv6 address and NTP address.

dhcp6c.conf: This file is to configure the IPv6 parameters for the DHCPv6 clients.

nscicfg.conf: This file is to configure the NCSI related configurations.

nsupdate.conf: This file is to configure the channel ID, package ID for the NCSI interface.

phycfg.conf: This file is to configure the link speed, duplex and MTU value for the specified interface.

dhcp.preip_4: This file is to store the pre IPv4 address. This file will be created at runtime.

NTP

Following files will be preserved.

ntp.conf: This file contains the NTP daemon protocol configuration parameters such as synchronization sources, nodes and other related information

ntp.stat: This file contains the auto or manual network type protocols

adjtime: This file contains the time to synchronize the system clock

Localtime: This file is the system link to the file local time or to the correct time zone in the system timezone directly.

Dependency Configurations - IPMI

SNMP

Following files will be preserved.

snmp_users.conf: This file contains the SNMP user configurations such as user name and password encryption mechanism for the specific users.

snmpcfg.conf: This file contains the SNMP users privilege levels such as ro user and rw user.

Dependency Configurations - NIL

SSH

Following files will be preserved.

ssh_config: This file contains the keyword argument pairs of configurations such as Address family, Accept Env, Allow, users, authorized key files etc.

ssh_host_dsa_key , **ssh_host_rsa_key**: These files contain the private parts of the host keys.

ssh_host_dsa_key.pub, **ssh_host_rsa_key.pub**: These files contain the public parts of the host keys.

[Dependency Configurations - NIL](#)

KVM

Following files will be preserved.

vmedia.conf: This file contains the modes of media such as cd, fc, hd and enable and disable flags for lmedia, rmedia and sd servers.

adviserd.conf: This file contains the mouse mode configurations and host machine physical keyboard language layout configured in the MDS project configuration.

autorecord.conf: This file contains the maximum size of the video record file, the maximum time length of the video record file and information about the remote machine path if it is enabled in MDS project configuration.

stunnel.conf: This file contains the information about the stunnel configuration. It will also contain advisor and media server's secure port if secure connection is enabled.

usermacro.conf: This file saves the user defined macro from the jviewer.

rmedia.conf: This file contains the image name and the remote machine information like IP address, user name, password, domain name and share type.

[Dependency Configurations - NIL](#)

Authentication

Following files will be preserved.

activedir.conf: This file contains the configurations such as sslenable, timeout, racdomain, adtype, adfilterdc1, adfilterdc2, adfilterdc3, username, password, and rolegroup information such as name domain and privileges.

openLdapGroup.conf: This file contains the oprnm ldap role group information such as name domain and privilege.

nsswitch.conf: This file contains the sources to obtain the name service information in the range of categories and in what order.

pam_withunix: This file contains the PAM Order of modules such as IPMI, LDAP, RADIUS and UNIX.

pam_wounix: This contains the PAM Order of modules such as IPMI,LDAP and RADIUS.

group: This file contains the Linux group. It stores the group information or defines the user group information in Linux.

passwd: This file contains the user login information for the Linux system

shadow: This file contains the encrypted password information for the clients.

ldap.conf: This file contains the ldap server configuration details such as bindn, binpw, pam_ password, nss_reconnect_tries, port, port secondary, host, host secondary.

radius.conf: This file contains the radius server IP address, port number, secret, timeout, privilege etc.

[Dependency Configurations – NIL](#)


Procedure

1. Click [Firmware Update or Restore Configuration](#) link to view Firmware Update or Restore Configuration page accordingly.
2. Select the required Preserve Configuration items by either choosing the items individually by selecting the appropriate check boxes or by selecting all or none using Check All.
3. Click [Save](#) to save the changes.

10.6 Restore Configuration

This page allows you to restore the configuration files from the client system to the BMC.

To open Restore Configuration page, click [Maintenance](#) → [Restore Configuration](#) from the menu bar. A sample screenshot of Restore Configuration page is shown below.



Restore Configuration page

The various fields Restore Configuration page are given below.

Config File: This option is used to select the file which was backup earlier.

Upload: To upload the backup file to restore the backup files.

Procedure for Restore Configuration:

1. Click [Browse](#) to select the configuration file that needs to be backup and used to Restore the configuration, when needed.
2. Click [Upload](#) to restore the backup files. The Restore Configuration page will appear as shown below.



Restore Configuration page


3. Click [OK](#) to upload the new configuration file and restore.

10.7 Restore Factory Default

This option is used to restore the factory defaults of the device firmware. This section lists the configuration items that will be preserved during restore factory default configuration.

Warning: Please note that after entering restore factory widgets, other web pages and services will not work. All open widgets will be closed automatically. The device will reset and reboot within few minutes.

To open Restore Factory Defaults page, click [Maintenance](#) → [Restore Factory Defaults](#) from the menu bar. A sample screenshot of Restore Factory Defaults page is shown below.



Restore Factory Default page

Procedure

1. Click [Preserve Configuration](#) to redirect to Preserve Configuration page, which is used to preserve the particular configuration not to be overwritten by the default configuration.
2. Click [Restore Factory Defaults](#) to restore the factory defaults of the device firmware.

10.8 System Administrator

This page is used to configure the System Administrator settings.

To open System Administrator page, click [Maintenance](#) → [System Administrator](#) from the menu bar. A sample screenshot of System Administrator page is shown below.

System Administrator page

The various fields of System Administrator page are given below.

Username: Username of System Administrator is a read only field.

Enable User Access: To enable user access for system administrator.

Change Password: To change the user's password.

NOTE

This field will not allow more than 64 characters.

- Password must be at least 8 characters long and White space is not allowed.


Save: To save the new configuration for system administrator.

Procedure:

1. Check [Enable User Access](#) to enable user access for system administrator..
2. Enable [Change Password](#) option to change the user password. This action enables the password fields.
3. Enter the new password in the Password field.
4. Re-enter the password in the Confirm Password field.
5. Click [Save](#) to save the changes.

Chapter 11. Sign Out

To log out from, click the [admin](#) on the top right corner of the screen. A sample screenshot of admin option is shown below.



Sign Out page

Click [Sign Out](#) to perform log out. A Warning message will be prompted you to proceed further, click [OK](#) to log out or [Cancel](#) to retain the interface.

Chapter 12. Flash Tools

The Flash Tools are command line utility programs used to upgrade the firmware using different medium like KCS, USB, and LAN. There are two tools, which are being used.

- YAFUFlash

12.1 YAFUFlash

Yet Another Firmware Upgrade Flash is a tool used for flashing the BMC. This utility is used for flashing in both Linux and Windows environment. There are three types of mediums used to flash the BMC. They are,

- Network
- USB
- KCS

All the three mediums are applicable for Windows and Linux environment. The medium can be selected as per your requirement.

NOTE

YAFU based firmware update using Signed Hashed image is only possible if enough RAM is available to upload the full firmware image before the update starts.

In YAFU firmware upgrade, only YAFU command set is allowed if Enable IPMI Command handling during flashing support is disabled in project configuration.

YAFU flashing process has the following timeout values.

LAN interface: 3600 seconds

USB interface: 1800 seconds

KCS interface: 5400 seconds

12.1.1 Installation in Windows

1. Open the command prompt and enter YafuFlash\Windows path.
2. This contains two files, Yafuflash.exe and LIBIPMI.dll.
3. **Format:** Yafuflash [OPTIONS] [MEDIUM] [FW_IMAGE_FILE], where Perform BMC Flash Update
 - -? Displays the utility usage
 - -h Displays the utility usage
 - -V Displays the version of the tool
 - -e List outs a few examples of the tool

[OPTIONS]

<i>-info</i>	<i>Displays information about existing FW and new FW.</i>
<i>-msi, -img-section-info</i>	<i>Displays information about current FW Sections.</i>
<i>-mi, -img-info</i>	<i>Displays information about current FW Versions.</i>
<i>-fb, -force-boot</i>	<i>Option to FORCE BootLoader upgrade during full upgrade. Also, skips user interaction in Interactive upgrade mode. This option is not allowed with Interactive upgrade option.</i>
<i>-pc, -preserve-config</i>	<i>Option to preserve Config Module during full upgrade. If platform supports Dual Image, this option skips user interaction, preserves config and continues update process. This option is not allowed with interactive upgrade option.</i>
<i>-q, -quite</i>	<i>Use the option to show the minimum flash progress details.</i>
<i>-i</i>	<i>Option to interactive upgrade (Upgrade only required modules)**</i>
<i>-f, -full</i>	<i>Performs full upgrade in Interactive Upgrade mode. Skips module wise upgrade</i>
<i>-ipc, -ignore-platform-check</i>	<i>If this image is for a different platform, this option skips user interaction and continues update process.</i>
<i>-idi, -ignore-diff-image</i>	<i>If this image differs from the currently programmed image, this option skips user interaction and continues update process.</i>
<i>-isi, -ignore-same-image</i>	<i>If this image is same as the currently programmed image, this option skips user interaction and continues update process.</i>
<i>-iml, -ignore-module-location</i>	<i>If module(s) of this image is/are in different locations, this option skips user interaction and continues update process.</i>
<i>-ibv, -ignore-boot-version</i>	<i>If bootloader version is different and -force-boot is not specified, this option skips user interaction and continues update process. The bootloader will be updated.</i>
<i>-iri, -ignore-reselect-image</i>	<i>Option skips reselecting the active image.</i>
<i>-inc, -ignore-non-preserve-config</i>	<i>Option skips the restore to default factor setting if the image shares the same configuration area.</i>
<i>-rp, -replace-publickey</i>	<i>Option to replace the Signed Image Key in Existing Firmware.</i>
<i>-vcf, -version-cmp-flash</i>	<i>Option to skip flashing modules only if the versions are same by selecting (N/n). Option (Y/y) Selects full firmware upgrade mode.</i>
<i>-non-interactive</i>	<i>This option skips user interaction. This option cannot be used along with 'ignore-diff-image', 'ignore-same-image', 'ignore-module-location' & '- ignore- boot-version' options.</i>

<i>-pXXX, -preserve-XXX</i>	<i>Option to preserve XXX configuration, where XXX falls in sdr, fru, sel, ipmi, auth, net, ntp, snmp, ssh, kvm and syslog. If the preserve status of the other configuration enabled then it will ask for the other configuration to be preserved.</i>
<i>-p-XXX, -preserve-XXX-ieo, -ignore-existing-overrides</i>	<i>Option to preserve only XXX configuration. -ignore-existing-overrides must be used with at least one preserve-XXX option.</i>
<i>-msp, -split-img</i>	<i>Option to flash the split image.</i>
<i>-f -XXX, -flash-XXX</i>	<i>Option to flash specific section in non-interactive mode. If it is split image need to give split-image along with this option, where XXX denotes name of the section, e.g. -flash-conf.</i>
<i>-sc, -skip-crc</i>	<i>Option to skip the CRC check</i>
<i>-sf, -skip-fmh</i>	<i>Option to skip the FMH check</i>
<i>-d</i>	<i>Option to specify the peripheral(Only for Dual Image Support) <bit0> - BMC <bit1> - BIOS</i>
<i>-a, -activate</i>	<i>Option to activate peripheral devices <BIT0> - BMC <BIT1> - BIOS</i>
<i>-nr, -no-reboot</i>	<i>Option to skip the reboot With online-flash support, If conf/extlog is not preserved, BMC will still reboot.</i>
<i>-bu, -block-upgrade</i>	<i>Option to Flash using Block by Block method</i>
[MEDIUM]	
<i>-cd</i>	<i>Option to use USB Medium</i>
<i>-nw, -ip, -u, -p, -host, _pa</i>	<i>Option to use Network Medium 'ip' Option to enter IP, when using Network Medium 'host' Option to enter host name, When using Network Medium 'u' Option to enter UserName, When using Network Medium 'p' Option to enter Password, When using Network Medium '_p' Option to enter Port Number.</i>
<i>-kcs</i>	<i>Option to use KCS medium.</i>
<i>-serial</i>	<i>Option to use serial interface.</i>
<i>-term</i>	<i>Option to use serial command, e.g. /dev/ttyS0.</i>
<i>-baudrate</i>	<i>Option to use baudrate of the serial terminal, e.g. 115200.</i>

[FW_IMAGE_FILE] *Firmware image file name [rom.ima].*

-pe, -preserve-extlog *Option to preserve extlog configuration during firmware flash.*

NOTE

'-preserve-config' and '-force-boot' option not be used in interactive upgrade.

Examples for Network Medium

Eg1: ./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -info

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of both existing firmware and new firmware.

Eg2: ./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware.

Eg3: ./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -force-boot

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade.

Eg4: ./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -preserve-config

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with preserve config params.

Eg5: ./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -force-boot -preserve-config

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade and preserve config params.

Eg6: ./Yafuflash -nw -host spxbmc -force-boot -preserve-config rom.ima

Description: This command works with network medium using the host name spxbmc, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade and preserve config params.

Eg7: ./Yafuflash -nw -ip 2000::2005 -force-boot rom.ima

Description: This command works with network medium using the ipv6 address 2000::2005, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade.

Eg8: ./Yafuflash -nw -ip 155.166.132.12 rom.ima -i

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima using interactive upgrade mode and user will be prompt to select the Number of modules and module names to upgrade.

Eg9: ./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-section-info

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of Existing Firmware.

Eg10: ./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-info

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of existing firmware Version.

Eg11: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin public.pem -replace-publickey`

Description: This command works with network medium using the ip 155.166.132.12, which replaces the public key in firmware.

Eg12: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-sdr`

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SDR as well as selected configurations.

Eg13: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-snmp -preserve-ntp`

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SNMP and NTP as well as selected configurations.

Eg14: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -ignore-existing-overrides`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg15: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -preserve-snmp -ignore-existing-overrides`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU and SNMP configurations only.

Eg16: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-reselect-image`

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg17: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-non-preserve-config`

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg18: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 0 rom.ima`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg19: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 1 rom.ima`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg20: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 2 rom.ima`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg21: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 3 rom.ima`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg22: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -quite`

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima with minimum progress details.

Eg23: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -split-img boot.ima`

Description: This command works with network medium to flash the boot split image.

Eg24: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin -split-img root.ima`

Description: This command works with network medium to flash the root split image.

Eg25: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin rom.ima -flash-root -flash-conf`

Description: This command works with network medium to flash root and conf section from rom. ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg26: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin boot.ima -split-img -flash-boot`

Description: This command works with network medium to flash root from boot.ima split image.

-flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg27: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -split-img -flash-www-flash-osimage`

Description: This command works with network medium to flash www and osimage from root. ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg28: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin rom.ima -preserve-extlog`

Description: This command works with network medium to preserve extended log configuration.

Eg29: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -split-img -preserve-extlog`

Description: This command works with network medium to preserve extended log configuration from split image.

Eg30: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -d 1 rom.ima`

Description: This command works with network medium to flash the image on specific peripheral device.

Eg31: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -d 1 root.ima -split-img`

Description: This command works with network medium to flash the split image on specific peripheral device.

Eg32: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin -bu root.ima.`

Description: This command works with network medium to flash the image on specific peripheral device by block by block upgrade.

Examples for USB Medium

Power Save Mode should be disabled for Flashing with Yafu USB Interface.

Eg1: `./Yafuflash -cd rom.ima -info`

Description: This command works with USB medium which displays the details of both Existing Firmware and new firmware.

Eg2: `./Yafuflash -cd rom.ima`

Description: This command works with USB medium which start to flash the new rom.ima to the existing firmware.

Eg3: `./Yafuflash -cd rom.ima -force-boot`

Description: This command works with USB medium which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade.

Eg4: `./Yafuflash -cd rom.ima -preserve-config`

Description: This command works with USB medium which start to flash the new rom.ima to the existing firmware with preserving config params.

Eg5: `./Yafuflash -cd rom.ima -force-boot -preserve-config`

Description: This command works with USB medium which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade and preserving config params.

Eg6: `./Yafuflash -cd rom.ima -i`

Description: This command works with USB medium, which start to flash the new rom.ima using interactive upgrade mode and user, will be prompt to select the Number of modules and module names to upgrade.

Eg7: `./Yafuflash -cd -img-section-info`

Description: This command works with USB medium which displays the details of Existing Firmware.

Eg8: `./Yafuflash -cd -img-info`

Description: This command works with USB medium which displays the details of Existing Firmware Version.

Eg9: `./Yafuflash -cd public.pem -replace-publickey`

Description: This command works with USB medium which replaces the public key in Existing Firmare.

Eg10: `./Yafuflash -cd rom.ima -preserve-sel -preserve-ipmi`

Description: This command works with USB medium, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SEL and IPMI as well as selected configurations.

Eg11: `./Yafuflash -cd rom.ima -preserve-sel -ignore-existing-overrides`

Description: This command works with USB medium, which start to flash the new rom.ima to the existing firmware with preserving FRU configurations only

Eg12: `./Yafuflash -cd rom.ima -ignore-reselect-image`

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg13: `./Yafuflash -cd rom.ima -ignore-non-preserve-config`

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg14: `./Yafuflash -cd -img-select 0 rom.ima`

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg15: `./Yafuflash -cd -img-select 1 rom.ima`

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg16: `./Yafuflash -cd -img-select 2 rom.ima`

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg17: `./Yafuflash -cd -img-select 3 rom.ima`

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg18: `./Yafuflash -cd rom.ima -quite`

Description: This command works with USB medium, which start to flash the new rom.ima with minimum progress details.

Eg19: `./Yafuflash -cd -split-img boot.ima`

Description: This command works with USB medium to flash the boot split image.

Eg20: `./Yafuflash -cd -split-img root.ima`

Description: This command works with USB medium to flash the root split image.

Eg21: `./Yafuflash -cd rom.ima -flash-root -flash-conf`

Description: This command works with USB medium to flash root and conf section from rom.ima file. `-flash-<xxx>`, where xxx specifies the modules in rom.ima.

Eg22: `./Yafuflash -cd boot.ima -split-img -flash-boot`

Description: This command works with USB medium to flash root from boot.ima split image. `-flash-<xxx>`, where xxx specifies the modules in boot.ima.

Eg23: `./Yafuflash -cd root.ima -split-img -flash-www -flash-osimage`

Description: This command works with USB medium to flash www and osimage from root.ima split image. `-flash-<xxx>`, where xxx specifies the modules in root.ima.

Eg24: `./Yafuflash -cd rom.ima -preserve-extlog`

Description: This command works with USB medium to preserve extended log configuration.

Eg25: `./Yafuflash -cd root.ima -split-img -preserve-extlog`

Description: This command works with USB medium to preserve extended log configuration from split image.

Eg26: `./Yafuflash -cd root.ima -d 1 rom.ima`

Description: This command works with USB medium to flash the image on specific peripheral device.

Eg27: `./Yafuflash -cd root.ima -d 1 root.ima -split-img`

Description: This command works with USB medium to flash the split image on specific peripheral device.

Examples for KCS Medium

Eg1: `./Yafuflash -kcs rom.ima -info`

Description: This command works with KCS medium which displays the details of both Existing Firmware and new firmware.

Eg2: `./Yafuflash -kcs rom.ima`

Description: This command works with KCS medium which start to flash the new rom.ima to the existing firmware.

Eg3: `./Yafuflash -kcs rom.ima -force-boot`

Description: This command works with KCS medium which start to flash the new rom.ima to the existing firmware with FORCE BootLoader upgrade.

Eg4: `./Yafuflash -kcs rom.ima -preserve-config`

Description: This command works with KCS medium which start to flash the new rom.ima to the existing firmware with preserving config params.

Eg5: `./Yafuflash -kcs rom.ima -force-boot -preserve-config`

Description: This command works with KCS medium which start to flash the new rom.ima to the existing firmware with FORCE BootLoader upgrade and preserving config params.

Eg6: `./Yafuflash -kcs rom.ima -i`

Description: This command works with KCS medium, which start to flash the new rom.ima using interactive upgrade mode and user, will be prompt to select the Number of modules and module names to upgrade.

Eg7: `./Yafuflash -kcs -img-section-info`

Description: This command works with KCS medium which displays the details of Existing Firmware.

Eg8: `./Yafuflash -kcs -img-info`

Description: This command works with KCS medium which displays the details of Existing Firmware Version.

Eg9: `./Yafuflash -kcs public.pem -replace-publickey`

Description: This command works with KCS medium which replaces the public key in Existing Firmware.

Eg10: `./Yafuflash -kcs rom.ima -preserve-sel -preserve-ipmi`

Description: This command works with KCS medium, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SEL and IPMI as well as selected configurations.

Eg11: `./Yafuflash -kcs rom.ima -preserve-sel -ignore-existing-overrides`

Description: This command works with KCS medium, which start to flash the new rom.ima to the existing firmware with preserving FRU configurations only

Eg12: `./Yafuflash -kcs rom.ima -ignore-reselect-image`

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg13: `./Yafuflash -kcs rom.ima -ignore-non-preserve-config`

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg14: `./Yafuflash -kcs -img-select 0 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg15: `./Yafuflash -kcs -img-select 1 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.
configuration.

Eg16: `./Yafuflash -kcs -img-select 2 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg17: `./Yafuflash -kcs -img-select 3 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg18: `./Yafuflash -kcs rom.ima -quite`

Description: This command works with KCS medium, which start to flash the new rom.ima with minimum progress details.

Eg19: `./Yafuflash -kcs -split-img boot.ima`

Description: This command works with KCS medium to flash the boot split image.

Eg20: `./Yafuflash -kcs -split-img root.ima`

Description: This command works with KCS medium to flash the root split image.

Eg21: `./Yafuflash -kcs rom.ima -flash-root -flash-conf`

Description: This command works with KCS medium to flash root and conf section from rom.ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg22: `./Yafuflash -kcs boot.ima -split-img -flash-boot`

Description: This command works with KCS medium to flash root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg23: `./Yafuflash -kcs root.ima -split-img -flash-www -flash-osimage`

Description: This command works with KCS medium to flash www and osimage from root.ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg24: `./Yafuflash -kcs rom.ima -preserve-extlog`

Description: This command works with KCS medium to preserve extended log configuration.

Eg25: `./Yafuflash -kcs root.ima -split-img -preserve-extlog`

Description: This command works with KCS medium to preserve extended log configuration from split image.

Eg26: `./Yafuflash -kcs root.ima -d 1 rom.ima`

Description: This command works with KCS medium to flash the image on specific peripheral device.

Eg27: `./Yafuflash -kcs root.ima -d 1 root.ima -split-img`

Description: This command works with KCS medium to flash the split image on specific peripheral device.

12.1.2 Installation in Linux

1. Open Terminal and go to YafuFlash/Linux path.
2. This contains Yafuflash tool.
3. Run ./Yafuflash in the terminal.
4. Format: ./Yafuflash [OPTIONS] [MEDIUM] [FW_IMAGE_FILE] where, Perform BMC Flash Update
 - -? Displays the utility usage
 - -h Displays the utility usage
 - -V Displays the version of the tool
 - -e List outs a few examples of the tool

[OPTIONS]

<i>-info</i>	<i>Displays information about existing FW and new FW.</i>
<i>-msi, -img-section-info</i>	<i>Displays information about current FW Sections.</i>
<i>-mi, -img-info</i>	<i>Displays information about current FW Versions.</i>
<i>-fb, -force-boot</i>	<i>Option to FORCE BootLoader upgrade during full upgrade. Also, skips user interaction in Interactive upgrade mode. This option is not allowed with Interactive upgrade option.</i>
<i>-pc, -preserve-config</i>	<i>Option to preserve Config Module during full upgrade. If platform supports Dual Image, this option skips user interaction, preserves config and continues update process. This option is not allowed with interactive upgrade option.</i>
<i>-q, -quite</i>	<i>Use the option to show the minimum flash progress details.</i>
<i>-i</i>	<i>Option to interactive upgrade (Upgrade only required modules)**</i>
<i>-f, -full</i>	<i>Performs full upgrade in Interactive Upgrade mode. Skips module wise upgrade</i>
<i>-ipc, -ignore-platform-check</i>	<i>If this image is for a different platform, this option skips user interaction and continues update process.</i>
<i>-idi, -ignore-diff-image</i>	<i>If this image differs from the currently programmed image, this option skips user interaction and continues update process.</i>
<i>-isi, -ignore-same-image</i>	<i>If this image is same as the currently programmed image, this option skips user interaction and continues update process.</i>
<i>-iml, -ignore-module-location</i>	<i>If module(s) of this image is/are in different locations, this option skips user interaction and continues update process.</i>
<i>-ibv, -ignore-boot-version</i>	<i>If bootloader version is different and -force-boot is not specified, this option skips user interaction and continues update process. The bootloader will be updated.</i>
<i>-iri, -ignore-reselect-image</i>	<i>Option skips reselecting the active image.</i>

<i>-inc, -ignore-non-preserve-config</i>	<i>Option skips the restore to default factor setting if the image shares the same configuration area.</i>
<i>-rp, -replace-publickey</i>	<i>Option to replace the Signed Image Key in Existing Firmware.</i>
<i>-vcf, -version-cmp-flash</i>	<i>Option to skip flashing modules only if the versions are same by selecting (N/n). Option (Y/y) Selects full firmware upgrade mode.</i>
<i>-non-interactive</i>	<i>This option skips user interaction. This option cannot be used along with 'ignore-diff-image', 'ignore-same- image','-ignore-module-location' & '-ignore- boot-version' options.</i>
<i>-pXXX, -preserve-XXX</i>	<i>Option to preserve XXX configuration, where XXX falls in sdr, fru, sel, ipmi, auth, net, ntp, snmp, ssh, kvm and syslog. If the preserve status of the other configuration enabled then it will ask for the other configuration to be preserved.</i>
<i>-p-XXX, -preserve-XXX-ieo , -ignore-existing-overrides</i>	<i>Option to preserve only XXX configuration. -ignore-existing-overrides must be used with at least one preserve-XXX option.</i>
<i>-msp, -split-img</i>	<i>Option to flash the split image.</i>
<i>-f-XXX, -flash-XXX</i>	<i>Option to flash specific section in non-interactive mode. If it is split image need to give split-image along with this option, where XXX denotes name of the section, e.g. -flash-conf.</i>
<i>-sc, -skip-crc</i>	<i>Option to skip the CRC check</i>
<i>-sf, -skip-fmh</i>	<i>Option to skip the FMH check</i>
<i>-d</i>	<i>Option to specify the peripheral(Only for Dual Image Support) <bit0> - BMC <bit1> - BIOS</i>
<i>-a, -activate</i>	<i>Option to activate peripheral devices <BIT0> - BMC <BIT1> - BIOS</i>
<i>-nr, -no-reboot</i>	<i>Option to skip the reboot With online-flash support, If conf/extlog is not preserved, BMC will still reboot.</i>
<i>-bu, -block-upgrade</i>	<i>Option to Flash using Block by Block method</i>

[MEDIUM]

<i>-cd</i>	<i>Option to use USB Medium</i>
<i>-nw, -ip, -u, -p, -host, _pa</i>	<i>Option to use Network Medium '-ip' Option to enter IP, when using Network Medium '-host' Option to enter host name, When using Network Medium '-u' Option to enter UserName, When using Network Medium '-p' Option to enter Password, When using Network Medium '_p' Option to enter Port Number.</i>
<i>-kcs</i>	<i>Option to use KCS medium.</i>
<i>-serial</i>	<i>Option to use serial interface.</i>
<i>-term</i>	<i>Option to use serial command, e.g. /dev/ttyS0.</i>
<i>-baudrate</i>	<i>Option to use baudrate of the serial terminal, e.g. 115200.</i>
[FW_IMAGE_FILE]	<i>Firmware image file name [rom.ima].</i>
<i>-pe, -preserve-extlog</i>	<i>Option to preserve extlog configuration during firmware flash.</i>

NOTE

'-preserve-config' and '-force-boot' option not be used in interactive upgrade.

NOTE

**IPv6 Support is added after the tool version 2.7. IPv6 Support can be used with latest Yafu tool and firmware, older version of yafu (and/or) firmware will not work.
**Interactive upgrade is not a default option. This option can be enabled in YafuFlash, if it is built with Enable/Disable Interactive Upgrade YafuFlash option selected in Project Configuration file (*.PRJ) using MDS.*

Examples for Network Medium

Eg1: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -info`

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of both existing firmware and new firmware.

Eg2: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima`

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware.

Eg3: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -force-boot`

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade.

Eg4: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -preserve-config`

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with preserve config params.

Eg5: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -force-boot -preserve-config`

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade and preserve config params.

Eg6: `./Yafuflash -nw -host spxbmc -force-boot -preserve-config rom.ima`

Description: This command works with network medium using the host name spxbmc, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade and preserve config params.

Eg7: `./Yafuflash -nw -ip 2000::2005 -force-boot rom.ima`

Description: This command works with network medium using the ipv6 address 2000::2005, which start to flash the new rom.ima to the existing firmware with FORCE BootLoader Upgrade.

Eg8: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -i`

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima using interactive upgrade mode and user will be prompt to select the Number of modules and module names to upgrade.

Eg9: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-section-info`

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of Existing Firmware.

Eg10: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-info`

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of existing firmware Version.

Eg11: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin public.pem -replace-publickey`

Description: This command works with network medium using the ip 155.166.132.12, which replaces the public key in firmware.

Eg12: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-sdr`

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SDR as well as selected configurations.

Eg13: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-snmp -preserve-ntp`

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SNMP and NTP as well as selected configurations.

Eg14: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -ignore-existing-overrides`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg15: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -preserve-snmp -ignore-existing-overrides`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU and SNMP configurations only.

Eg16: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-reselect-image`

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg17: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-non-preserve-config`

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg18: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 0 rom.ima`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg19: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 1 rom.ima`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg20: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 2 rom.ima`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg21: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-select 3 rom.ima`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg22: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -quite`

Description: This command works with network medium using the ip 155.166.132.12, which start to flash the new rom.ima with minimum progress details.

Eg23: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -split-img boot.ima`

Description: This command works with network medium to flash the boot split image.

Eg24: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin -split-img root.ima`
Description: This command works with network medium to flash the root split image.

Eg25: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin rom.ima -flash-root -flash-conf`

Description: This command works with network medium to flash root and conf section from rom. ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg26: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin boot.ima -split-img -flash-boot`

Description: This command works with network medium to flash root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg27: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -split-img -flash-www-flash-osimage`

Description: This command works with network medium to flash www and osimage from root. ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg28: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin rom.ima -preserve-extlog`

Description: This command works with network medium to preserve extended log configuration.

Eg29: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -split-img -preserve-extlog`

Description: This command works with network medium to preserve extended log configuration from split image.

Eg30: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -d 1 rom.ima`

Description: This command works with network medium to flash the image on specific peripheral device.

Eg31: `./Yafuflash -nw-ip 155.166.132.12 -u admin -p admin root.ima -d 1 root.ima -split-img`

Description: This command works with network medium to flash the split image on specific peripheral device.

```

You have new mail in /var/spool/mail/root
[root@localhost linux_96]# ./Yafuflash -nw -ip 10.0.0.120 -u root -p superuser -
./romP.ima
-----
YAFUFlash - Firmware Upgrade Utility (Version 2.1)
-----
(C) Copyright 2008, American Megatrends Inc.

Creating IPMI session via network with address 10.0.0.120...Done
-----
                          Firmware Details
-----
RomImage              ExistingImage from Flash
-----
ModuleName  Description  Version  ModuleName  Description  Version
1. boot      BootLoader  9.19     boot        BootLoader  9.19
2. params    ConfigParams 9.19     params      ConfigParams 9.19
3. root      Root         9.19     root        Root         9.19
4. osimage   Linux OS     9.19     osimage     Linux OS     9.19
5. www       Web Pages   9.19     www         Web Pages   9.19
6. cim       CIM         9.19     cim         CIM         9.19
7. aviator   Aviator     9.19     aviator     Aviator     9.19

Existing Image and Current Image are Same
So, Type (Y/y) to do Full Firmware Upgrade or (N/n) to exit
Enter your Option : Y
-----
WARNING!
FIRMWARE UPGRADE MUST NOT BE INTERRUPTED ONCE IT IS STARTED.
PLEASE DO NOT USE THIS FLASH TOOL FROM THE REDIRECTION CONSOLE.
-----
Uploading Firmware Image : 100%... done
Flashing Firmware Image : 100%... done
Verifying Firmware Image : 100%... done
Resetting the firmware.....

```

Screen: If Existing and current images are same

```

root@localhost:~/megarac/SP/6April/winbond/development/proprietary/software/YafuFlash/linux_86
[root@localhost linux_86]# ./Yafuflash -nw -ip 10.0.0.120 -u root -p superuser ../romP.ima -force-boot
YAFUFlash - Firmware Upgrade Utility (Version 2.1)
-----
(C)Copyright 2008, American Megatrends Inc.

Creating IPMI session via network with address 10.0.0.120...Done
*****
WARNING!
FIRMWARE UPGRADE MUST NOT BE INTERRUPTED ONCE IT IS STARTED.
PLEASE DO NOT USE THIS FLASH TOOL FROM THE REDIRECTION CONSOLE.
*****
Preserving Env Variables...      done
Setting Env variables ...      done
Upgrading Firmware Image : 100%... done
Resetting the firmware.....
[root@localhost linux_86]#

```

FG: 2 - Existing and current are different

```

[root@muthu Linux_x86_32]# ./Yafuflash -nw -ip 10.0.3.5 -u admin -p admin rom.ima -i
YAFUFlash - Firmware Upgrade Utility (Version 2.11)
-----
(C)Copyright 2008, American Megatrends Inc.

Creating IPMI session via network with address 10.0.3.5...Done
-----
Firmware Details
-----
RomImage      ExistingImage from Flash
-----
ModuleName    Description    Version      ModuleName    Description    Version
1. boot        BootLoader    1.4.00      boot          BootLoader    1.4.00
2. conf        ConfigParams  1.4.00      conf          ConfigParams  1.4.00
3. bkupconf    Root          1.4.00      bkupconf     Root          1.4.00
4. root        Linux OS      1.4.00      root          Root          1.4.00
5. osimage     Web Pages     1.4.00      osimage      Linux OS      1.4.00
6. www         Web Pages     1.4.00      www           Web Pages     1.4.00
7. lmedia      1.4.00       lmedia       1.4.00
8. hornet      1.4.00       hornet       1.4.00

For Full Firmware upgrade,Please type (0) alone
For Module Upgrade enter the total no. of Modules to Upgrade
Enter your choice : 4
Enter the Module Name to Update : boot

```

FG: 3 - Interactive Upgrade Mode

Eg32: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -bu root.ima.`

Description: This command works with network medium to flash the image on specific peripheral device by block by block upgrade.

Examples for USB Medium

Eg1:./Yafuflash –cd rom.ima -info

Description: This command works with USB medium which displays the details of both Existing Firmware and new firmware.

Eg2:./Yafuflash –cd rom.ima

Description: This command works with USB medium which start to flash the new rom.ima to the existing firmware.

Eg3: ./Yafuflash –cd rom.ima –force-boot

Description: This command works with USB medium which start to flash the new rom.ima to the existing firmware with FORCE BootLoader upgrade.

Eg4: ./Yafuflash –cd rom.ima –preserve-config

Description: This command works with USB medium which start to flash the new rom.ima to the existing firmware with preserving config params.

Eg5: ./Yafuflash –cd rom.ima –force-boot –preserve-config

Description: This command works with USB medium which start to flash the new rom.ima to the existing firmware with FORCE BootLoader upgrade and preserving config params.

Eg6: ./Yafuflash –cd rom.ima -i

Description: This command works with USB medium, which start to flash the new rom.ima using interactive upgrade mode and user, will be prompt to select the Number of modules and module names to upgrade.

Eg7: ./Yafuflash –cd -img-section-info

Description: This command works with USB medium which displays the details of Existing Firmware.

Eg8: ./Yafuflash –cd -img-info

Description: This command works with USB medium which displays the details of Existing Firmware Version.

Eg9: ./Yafuflash –cd public.pem –replace-publickey

Description: This command works with USB medium which replaces the public key in Existing Firmare.

Eg10 : ./Yafuflash -cd rom.ima -preserve-sel -preserve-ipmi

Description: This command works with USB medium, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SEL and IPMI as well as selected configurations.

Eg11: ./Yafuflash -cd rom.ima -preserve-sel -ignore-existing-overrides

Description: This command works with USB medium, which start to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg12: ./Yafuflash –cd rom.ima –ignore-reselect-image

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg13: ./Yafuflash –cd rom.ima –ignore-non-preserve-config

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg14: `./Yafuflash -cd -img-select 0 rom.ima`

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg15: `./Yafuflash - cd -ip 155.166.132.12 -u admin -p admin -img-select 0 rom.ima`

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg16: `./Yafuflash - cd -ip 155.166.132.12 -u admin -p admin -img-select 1 rom.ima`

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg17: `./Yafuflash - cd -ip 155.166.132.12 -u admin -p admin -img-select 2 rom.ima`

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting the second image to be flashed.

Eg18: `./Yafuflash - cd -ip 155.166.132.12 -u admin -p admin -img-select 3 rom.ima`

Description: This command works with USB medium, which starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg19: `./Yafuflash -cd rom.ima -quite`

Description: This command works with USB medium, which start to flash the new rom.ima with minimum progress details.

Eg20: `./Yafuflash -cd -split-img boot.ima`

Description: This command works with USB medium to flash the boot split image.

Eg21: `./Yafuflash -cd -split-img root.ima`

Description: This command works with USB medium to flash the root split image.

Eg22: `./Yafuflash -cd rom.ima -flash-root -flash-conf`

Description: This command works with USB medium to flash root and conf section from rom.ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg23: `./Yafuflash -cd boot.ima -split-img -flash-boot`

Description: This command works with USB medium to flash root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg24: `./Yafuflash -cd root.ima -split-img -flash-www -flash-osimage`

Description: This command works with USB medium to flash www and osimage from root.ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg25: `./Yafuflash -cd rom.ima -preserve-extlog`

Description: This command works with USB medium to preserve extended log configuration.

Eg26: `./Yafuflash -cd root.ima -split-img -preserve-extlog`

Description: This command works with USB medium to preserve extended log configuration from split image.

Eg27: `./Yafuflash -cd root.ima -d 1 rom.ima`

Description: This command works with USB medium to flash the image on specific peripheral device.

Eg28: `./Yafuflash -cd root.ima -d 1 root.ima -split-img`

Description: This command works with USB medium to flash the split image on specific peripheral device.

Examples for KCS Medium

Eg1: `./Yafuflash -kcs rom.ima -info`

Description: This command works with KCS medium which displays the details of both Existing Firmware and new firmware.

Eg2: `./Yafuflash -kcs rom.ima`

Description: This command works with KCS medium which start to flash the new rom.ima to the existing firmware.

Eg3: `./Yafuflash -kcs rom.ima -force-boot`

Description: This command works with KCS medium which start to flash the new rom.ima to the existing firmware with FORCE BootLoader upgrade.

Eg4: `./Yafuflash -kcs rom.ima -preserve-config`

Description: This command works with KCS medium which start to flash the new rom.ima to the existing firmware with preserving config params.

Eg5: `./Yafuflash -kcs rom.ima -force-boot -preserve-config`

Description: This command works with KCS medium which start to flash the new rom.ima to the existing firmware with FORCE BootLoader upgrade and preserving config params.

Eg6: `./Yafuflash -kcs rom.ima -i`

Description: This command works with KCS medium, which start to flash the new rom.ima using interactive upgrade mode and user, will be prompt to select the Number of modules and module names to upgrade.

Eg7: `./Yafuflash -kcs -img-section-info`

Description: This command works with KCS medium which displays the details of Existing Firmware.

Eg8: `./Yafuflash -kcs -img-info`

Description: This command works with KCS medium which displays the details of Existing Firmware Version.

Eg9: `./Yafuflash -kcs public.pem -replace-publickey`

Description: This command works with KCS medium which replaces the public key in Existing Firmware.

Eg10: `./Yafuflash -kcs rom.ima -preserve-sel -preserve-ipmi`

Description: This command works with KCS medium, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SEL and IPMI as well as selected configurations.

Eg11: `./Yafuflash -kcs rom.ima -preserve-sel -ignore-existing-overrides`

Description: This command works with KCS medium, which start to flash the new rom.ima to the existing firmware with preserving FRU configurations only

Eg12: `./Yafuflash -kcs rom.ima -ignore-reselect-image`

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg13: `./Yafuflash -kcs rom.ima -ignore-non-preserve-config`

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg14: `./Yafuflash -kcs -img-select 0 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg15: `./Yafuflash -kcs -img-select 1 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg16: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-section-info`

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of Existing Firmware.

Eg17: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin -img-info`

Description: This command works with network medium using the ip 155.166.132.12, which displays the details of Existing Firmware Version.

Eg18: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin public.pem -replace-publickey`

Description: This command works with network medium using the ip 155.166.132.12, which replaces the public key in Existing Firmware.

Eg19: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-sdr`

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SDR as well as selected configurations.

Eg20: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-snmp -preserve-ntp`

Description: This command works with network medium using the ip 155.166.132.12, which will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SNMP and NTP as well as selected configurations.

Eg21: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -ignore-existing-overrides`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg22: `./Yafuflash -nw -ip 155.166.132.12 rom.ima -preserve-fru -preserve-snmp -ignore-existing-overrides`

Description: This command works with network medium using the ip 155.166.132.12, which starts to flash the new rom.ima to the existing firmware with preserving FRU and SNMP configurations only.

Eg23: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-reselect-image`

Description: Yafuflash start full firmware upgrade with default active image. In this it skips the reselecting active image used to flash.

Eg24: `./Yafuflash -nw -ip 155.166.132.12 -u admin -p admin rom.ima -ignore-non-preserve-config`

Description: Yafuflash start full firmware upgrade, If the Images of both flash share the same Configuration area. Not preserving will restore to default factory settings, this option skips it.

Eg25: `./Yafuflash -kcs -img-select 2 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by **selecting the second image to be flashed.**

Eg26: `./Yafuflash -kcs -img-select 3 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg27: `./Yafuflash -kcs rom.ima -quite`

Description: This command works with KCS medium, which start to flash the new rom.ima with minimum progress details.

Eg28: `./Yafuflash -kcs -split-img boot.ima`

Description: This command works with KCS medium to flash the boot split image.

Eg29: `./Yafuflash -kcs -split-img root.ima`

Description: This command works with KCS medium to flash the root split image.

Eg30: `./Yafuflash -kcs rom.ima -flash-root -flash-conf`

Description: This command works with KCS medium to flash root and conf section from rom.ima file. -flash-<xxx>, where xxx specifies the modules in rom.ima.

Eg31: `./Yafuflash -kcs boot.ima -split-img -flash-boot`

Description: This command works with KCS medium to flash root from boot.ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg32: `./Yafuflash -kcs root.ima -split-img -flash-www -flash-osimage`

Description: This command works with KCS medium to flash www and osimage from root.ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg33: `./Yafuflash -kcs rom.ima -preserve-extlog`

Description: This command works with KCS medium to preserve extended log configuration.

Eg34: `./Yafuflash -kcs root.ima -split-img -preserve-extlog`

Description: This command works with KCS medium to preserve extended log configuration from split image.

Eg35: `./Yafuflash -kcs root.ima -d 1 rom.ima`

Description: This command works with KCS medium to flash the image on specific peripheral device.

Eg36: `./Yafuflash -kcs root.ima -d 1 root.ima -split-img`

Description: This command works with KCS medium to flash the split image on specific peripheral device.

YAFUFlash OS Compatibility

YafuFlash	Test On 32bit OS					Test On 64bit OS				
	Windows Server 2008 SP2	RHEL5.4	RHEL6.0	SLES 11	Ubuntu server 10.04	Windows Server 2008 SP2	RHEL5.4	RHEL6.0	SLES 11	Ubuntu server 10.04
Preserve Config	Result	Result	Result	Result	Result	Result	Result	Result	Result	Result
USB medium: YafuFlash -cd fw_image -preserve -config	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
Network medium: YafuFlash -ip_BMC_IP -u admin -p admin fw_image -preserve -config	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
Force Update	Result	Result	Result	Result	Result	Result	Result	Result	Result	Result
USB medium: YafuFlash -cd fw_image -force-boot	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass
Network medium: YafuFlash -ip_BMC_IP -u admin -p admin fw_image -force-boot	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass	Pass

12.1.3 Installation in DOS

1. Copy Yafuflash.exe into DOS machine
2. Run Yafuflash utility.
3. Format: Yafuflash [OPTIONS] [MEDIUM] [FW_IMAGE_FILE] where, Perform BMC Flash Update
 - -? Displays the utility usage
 - -h Displays the utility usage
 - -V Displays the version of the tool
 - -e List out a few examples of the tool

[OPTIONS]

<i>-info</i>	<i>Displays information about existing FW and new FW.</i>
<i>-msi, -img-section-info</i>	<i>Displays information about current FW Sections.</i>
<i>-mi, -img-info</i>	<i>Displays information about current FW Versions.</i>
<i>-fb, -force-boot</i>	<i>Option to FORCE BootLoader upgrade during full upgrade. Also, skips user interaction in Interactive upgrade mode. This option is not allowed with Interactive upgrade option.</i>
<i>-pc, -preserve-config</i>	<i>Option to preserve Config Module during full upgrade. If platform supports Dual Image, this option skips user interaction, preserves config and continues update process. This option is not allowed with interactive upgrade option.</i>
<i>-q, -quite</i>	<i>Use the option to show the minimum flash progress details.</i>
<i>-i</i>	<i>Option to interactive upgrade (Upgrade only required modules)**</i>
<i>-f, -full</i>	<i>Performs full upgrade in Interactive Upgrade mode. Skips module wise upgrade</i>
<i>-ipc, -ignore-platform-check</i>	<i>If this image is for a different platform, this option skips user interaction and continues update process.</i>
<i>-idi, -ignore-diff-image</i>	<i>If this image differs from the currently programmed image, this option skips user interaction and continues update process.</i>
<i>-isi, -ignore-same-image</i>	<i>If this image is same as the currently programmed image, this option skips user interaction and continues update process.</i>
<i>-iml, -ignore-module-location</i>	<i>If module(s) of this image is/are in different locations, this option skips user interaction and continues update process.</i>
<i>-ibv, -ignore-boot-version</i>	<i>If bootloader version is different and -force-boot is not specified, this option skips user interaction and continues update process. The bootloader will be updated.</i>
<i>-iri, -ignore-reselect-image</i>	<i>Option skips reselecting the active image.</i>

<i>-inc, -ignore-non-preserve-config</i>	<i>Option skips the restore to default factor setting if the image shares the same configuration area.</i>
<i>-rp, -replace-publickey</i>	<i>Option to replace the Signed Image Key in Existing Firmware.</i>
<i>-vcf, -version-cmp-flash</i>	<i>Option to skip flashing modules only if the versions are same by selecting (N/n). Option (Y/y) Selects full firmware upgrade mode.</i>
<i>-non-interactive</i>	<i>This option skips user interaction. This option cannot be used along with 'ignore-diff-image', 'ignore-same-image', 'ignore-module-location' & 'ignore-boot-version' options.</i>
<i>-pXXX, -preserve-XXX</i>	<i>Option to preserve XXX configuration, where XXX falls in sdr, fru, sel, ipmi, auth, net, ntp, snmp, ssh, kvm and syslog. If the preserve status of the other configuration enabled then it will ask for the other configuration to be preserved.</i>
<i>-p-XXX, -preserve-XXX-ieo, -ignore-existing-overrides</i>	<i>Option to preserve only XXX configuration. -ignore-existing-overrides must be used with at least one preserve-XXX option.</i>
<i>-msp, -split-img</i>	<i>Option to flash the split image.</i>
<i>-f-XXX, -flash-XXX</i>	<i>Option to flash specific section in non-interactive mode. If it is split image need to give split-image along with this option, where XXX denotes name of the section, e.g. -flash-conf.</i>
<i>-sc, -skip-crc</i>	<i>Option to skip the CRC check</i>
<i>-sf, -skip-fmh</i>	<i>Option to skip the FMH check</i>
<i>-d</i>	<i>Option to specify the peripheral(Only for Dual Image Support) <bit0> - BMC <bit1> - BIOS</i>
<i>-a, -activate</i>	<i>Option to activate peripheral devices <BIT0> - BMC <BIT1> - BIOS</i>
<i>-nr, -no-reboot</i>	<i>Option to skip the reboot With online-flash support, If conf/extlog is not preserved, BMC will still reboot.</i>
<i>-bu, -block-upgrade</i>	<i>Option to Flash using Block by Block method</i>

[MEDIUM]

<i>-cd</i>	<i>Option to use USB Medium</i>
<i>-nw, -ip, -u, -p, -host, _pa</i>	<i>Option to use Network Medium '-ip' Option to enter IP, when using Network Medium '-host' Option to enter host name, When using Network Medium '-u' Option to enter UserName, When using Network Medium '-p' Option to enter Password, When using Network Medium '_p' Option to enter Port Number.</i>
<i>-kcs</i>	<i>Option to use KCS medium.</i>
<i>-serial</i>	<i>Option to use serial interface.</i>
<i>-term</i>	<i>Option to use serial command, e.g. /dev/ttyS0.</i>
<i>-baudrate</i>	<i>Option to use baudrate of the serial terminal, e.g. 115200.</i>
[FW_IMAGE_FILE]	<i>Firmware image file name [rom.ima].</i>
<i>-pe, -preserve-extlog</i>	<i>Option to preserve extlog configuration during firmware flash.</i>

Firmware image file name [rom.ima].

NOTE

**Interactive upgrade is not a default option. This option can be enabled in YafuFlash, if it is built with Enable/Disable Interactive Upgrade YafuFlash option selected in Project Configuration file (*.PRJ) using MDS.

Examples

Eg1: Yafuflash -kcs -info rom.ima

Description: Displays the details of both Existing Firmware and new firmware.

Eg2: Yafuflash -kcs rom.ima

Description: This command starts to flash the new rom.ima to the existing firmware.

Eg3: Yafuflash -kcs -force-boot rom.ima

Description: This command starts to flash the new rom.ima to the firmware with FORCE BootLoader upgrade.

Eg4: Yafuflash -kcs -preserve-config rom.ima

Description: This command starts to flash the new rom.ima to the existing firmware with preserving config params.

Eg5: Yafuflash -kcs -force-boot -preserve-config rom.ima

Description: This command starts to flash the new rom.ima to the firmware with FORCE BootLoader upgrade and preserving config params.

Eg6: `Yafuflash -kcs -i rom.ima`

Description: This command starts to flash the new rom.ima using interactive upgrade mode and user, will be prompt to select the number of modules and module names to upgrade.

Eg7: `Yafuflash -kcs -img-section-info`

Description: Displays the details of Existing Firmware.

Eg8: `Yafuflash -kcs -img-info`

Description: Displays the details of Existing Firmware Version.

Eg9: `Yafuflash -kcs public.pem -replace-publickey`

Description: Replaces the public key in Existing Firmware.

Eg10: `Yafuflash -kcs rom.ima -preserve-sdr`

Description: This command will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SDR as well as selected configurations.

Eg11: `Yafuflash -kcs rom.ima -preserve-snmp -preserve-ntp`

Description: This command will ask for other configurations which are already set to be preserved to preserve or not and after that it will start to flash the new rom.ima to the existing firmware with preserving SNMP and NTP as well as selected configurations.

Eg12: `Yafuflash -kcs rom.ima -preserve-fru -ignore-existing-overrides`

Description: This command starts to flash the new rom.ima to the existing firmware with preserving FRU configurations only.

Eg13: `Yafuflash -kcs rom.ima -preserve-fru -preserve-snmp -ignore-existing-overrides`

Description: This command starts to flash the new rom.ima to the existing firmware with preserving FRU and SNMP configurations only.

Eg14: `Yafuflash -kcs -img-select 0 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the active image to be flashed.

Eg15: `Yafuflash -kcs -img-select 1 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by selecting the first image to be flashed.

Eg16: `Yafuflash -kcs -img-select 2 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by the selecting the second image to be flashed.

Eg17: `Yafuflash -kcs -img-select 3 rom.ima`

Description: This command starts to flash the new rom.ima to the existing firmware by selecting both the images to be flashed.

Eg18: `Yafuflash -kcs -split-img boot.ima`

Description: This command works with KCS medium to flash the boot split image.

Eg19: `Yafuflash -kcs -split-img boot.ima`

Description: This command works with KCS medium to flash the root split image.

Eg20: `Yafuflash -kcs rom.ima -flash root -flash-conf`

Description: This command works with KCS medium to flash the root and conf section from rom.ima file. `-flash-<xxx>`, where xxx specifies the modules in rom.ima.

Eg21:/Yafuflash -kcs boot.ima -split-img -flash-boot

Description: This command works with KCS medium to flash the root and boot,ima split image. -flash-<xxx>, where xxx specifies the modules in boot.ima.

Eg22:/Yafuflash -kcs rom.ima -split-img -flash-ww -flash-osimage

Description: This command works with KCS medium to flash www and osimage from root.ima split image. -flash-<xxx>, where xxx specifies the modules in root.ima.

Eg23:/Yafuflash -kcs rom.ima -preserve-extlog

Description: This command works with KCS medium to preserve extended log configuration.

Eg24:/Yafuflash -kcs root.ima -split-img -preserve-extlog

Description: This command works with KCS medium to preserve extended log configuration from split image.

Eg25:/Yafuflash -kcs root.ima -d 1 rom.ima

Description: This command works with KCS medium to flash the image on specific peripheral device.

Eg26:/Yafuflash -kcs root.ima -d 1 rom.ima -split-img

Description: This command works with KCS medium to flash the split image on specific peripheral device.

Eg27:/Yafuflash -nw-up 155.166.132 -u admin -p admin -bu root.ima

Description: This command works with network medium to flash the image on specific peripheral device by block by block upgrade.

Chapter 13. VMCLI

The Virtual Media Command Line Interface (VMCLI) utility is a scriptable command-line interface that provides virtual media features from the management station to the Host.

VMCLI is used to redirect the virtual media (Hard Disk, Floppy, CD drive, USB..) from the management station to the host.

Features:

- Removable media devices or image files that are consistent with the Virtual Media plugins
- Automatic termination when the host firmware boot once option is enabled
- Secure communication to the host using Secure Sockets Layer (SSL)


13.1 Installation in Windows

1. VMCLI can be installed in windows using batch file, installer.bat in VMCLI folder.

NOTE

You must keep wget inside the VMCLI Folder, which is the support Tool for VMCLI.

2. Go to VMCLI folder and execute the installer script to install the VMCLI service.
Installer.bat -i



3. Installer script will add the VMCLI as windows service and user can start and stop the service using sc command.

4. Start the VMCLI Service. Where VMCLI is service name.

Format: sc start VMCLI [-r][IP : Web-SSLPort] [-u][RAC-USER] [-p] [RAC- PASSWORD] [MEDIA TYPE] [MEDIA][-e] , where

[IP: Web-SSLPort]	IP Address: Port Number
IPv4	IPv4 format address e.g.: 10.0.6.8:443
IPv6	IPv6 format address e.g.: [2004::2000]:443
Web-SSLPort	IP should be given with in Ankle bracket like [2004::2000] for IPV6 HTTPS port number
[RAC- USER]	User Name User id, with 'virtual media' privilege Password
[RAC- PASSWORD]	User password, with 'virtual media' privilege

[MEDIA TYPE]


- c CD/DVD Drive and CD/DVD Image Floppy
- f Drive and Floppy Image
- hd Hard Disk Drive, Hard Disk Image and USB

[MEDIA] Media drive (or) Media Image

Media

For Hard Disk Drive need to mention physical drive volume name like C:/ ,D:/ etc. To know physical drive volumes go to Control panel → Administrative Tools → Computer Management → Storage → Disk Management (Refer Screen: Media Drive)

[-e] Enable encrypted data transfer through ssl



5. Stop the VMCLI service. Sc stop VMCLI.

```

C:\WINDOWS\system32\cmd.exe
E:\vmcli\Release>sc start vmcli

SERVICE_NAME: vmcli
        TYPE               : 10  WIN32_OWN_PROCESS
        STATE                : 4   RUNNING
                        (STOPPABLE,NOT_PAUSABLE,ACCEPTS_SHUTDOWN)
        WIN32_EXIT_CODE       : 0    (0x0)
        SERVICE_EXIT_CODE   : 0    (0x0)
        CHECKPOINT           : 0x0
        WAIT_HINT            : 0x0
        PID                  : 3140
        FLAGS                 :

E:\vmcli\Release>sc stop vmcli

SERVICE_NAME: vmcli
        TYPE               : 10  WIN32_OWN_PROCESS
        STATE                : 1   STOPPED
                        (NOT_STOPPABLE,NOT_PAUSABLE,IGNORES_SHUTDOWN)
        WIN32_EXIT_CODE       : 0    (0x0)
        SERVICE_EXIT_CODE   : 0    (0x0)
        CHECKPOINT           : 0x0
        WAIT_HINT            : 0x0

E:\vmcli\Release>

```

The above VMCLI Screen 1 starts VMCLI service without command line argumentie, configuration will be read from conf file.

Examples of Floppy Media redirection

Eg1:

IPv4: sc start VMCLI -r 10.0.6.8:443 -u admin -p admin -f A:\

IPv6: sc start VMCLI -r [2004::2000]:443 -u admin -p admin -f A:\

Description: This command is to redirect the floppy drive from the management station to the host.

Eg2:

IPv4: sc start VMCLI -r 10.0.6.8:443 -u admin -p admin -f "/home/fd.img"

IPv6: sc start VMCLI -r [2004::2000]:443 -u admin -p admin -f "/home/fd.img"

Description: This command is to redirect the floppy image from the management station to the host. The image file path is full system path.

Eg3:

IPv4: sc start VMCLI -r 10.0.6.8:443 -u admin -p admin -f FloppyImage.img -e

IPv6: sc start VMCLI -r [2004::2000]:443 -u admin -p admin -f FloppyImage.img -e

Description: This command is to redirect the floppy image from the management station to the host. Data will be transfer through ssl.

Eg4: sc stop VMCLI

Description: This command is used to stop the VMCLI service to stop the redirection.

Examples of CD-ROM Media redirection

Eg1:

IPv4: sc start VMCLI -r 10.0.6.8:443 -u admin -p admin -c E:\

IPv6: sc start VMCLI -r [2004::2000]:443 -u admin -p admin -c E:\

Description: This command is to redirect the CD/DVD drive from the management station to the host.

Eg2:

IPv4: sc start VMCLI -r 10.0.6.8:443 -u admin -p admin -c E:\ -e

IPv6: sc start VMCLI -r [2004::2000]:443 -u admin -p admin -c E:\ -e

Description: This command is to redirect the CD/DVD drive from the management station to the host. Data will be transfer through ssl.

Eg3:

IPv4: sc start VMCLI -r 10.0.6.8:443 -u admin -p admin -c "/home/cdrom.iso"

IPv6: sc start VMCLI -r [2004::2000]:443 -u admin -p admin -c "/home/cdrom.iso"

Description: This command is to redirect the CD image from the management station to the host. The image file path is full system path.

Eg4: sc stop VMCLI

Description: This command is used to stop the VMCLI service to stop the redirection.

Examples of Hard Disk Drive Media redirection**Eg1:**

IPv4: sc start VMCLI -r 10.0.6.8:443 -u admin -p admin -hd D:/

IPv6: sc start VMCLI -r [2004::2000]:443 -u admin -p admin -hd D:/

Description: This command is to redirect the Hard disk drive from the management station to the host.

Eg2:

IPv4: sc start VMCLI -r 10.0.6.8:443 -u admin -p admin -hd D:/ -e

IPv6: sc start VMCLI -r [2004::2000]:443 -u admin -p admin -hd D:/ -e

Description: This command is to redirect the Hard disk drive from the management station to the host. Data will be transfer through ssl/

Eg3:

IPv4: sc start VMCLI -r 10.0.6.8:443 -u admin -p admin -hd "/home/hd.img"

IPv6: sc start VMCLI -r [2004::2000]:443 -u admin -p admin -hd "/home/hd.img"

Description: This command is to redirect the floppy image from the management station to the host. The image file path is full system path.

Eg4: sc stop VMCLI

Description: This command is used to stop the VMCLI service to stop the redirection.

13.2 Installation in Linux

1. Search libssl.so.0.9.8e and libcrypto.so.0.9.8e locate at /usr/lib or not. If not, doyum install openssl libssl or rpm -ivh openssl.rpm and rpm -ivh libssl.rpm:

```
ls -l /usr/lib/libssl*
```

```
ls -l /usr/lib/libcrypto*
```

NOTE

For Ubuntu look in the path /lib/x86_64-linux-gnu or /lib/i386-linux- gnu 2. Create a force link as libssl.so.0.9.8e to libssl.so.4:

```
ln -sf libssl.so.0.9.8e libssl.so.4
```

2. Create a force link as libssl.so.0.9.8e to libssl.so.4:

```
ln -sf libssl.so.0.9.8e libssl.so.4
```

3. Create a force link as libcrypto.so.0.9.8e to libcrypto.so.4:

```
ln -sf libcrypto.so.0.9.8e libcrypto.so.4
```

4. Copy libssl.so.4 and libcrypto.so.4 to /lib and /usr/local/lib:


```
cp libssl.so.4 /lib/
cp libssl.so.4 /usr/local/lib
cp libcrypto.so.4 /lib/
cp libcrypto.so.4 /usr/local/lib
```
5. Open Terminal and go to VMCLI folder
6. Install the VMCLI service in Linux system using installer script


```
sudo bash ./installer.sh -i
```
7. Start and stop the VMCLI using service command.

Format:

Service vmcli start [-r] [IP:Web-SSLPort] [-u] [RAC-USER] [-p][RAC- PASSWORD] [MEDIA TYPE] [MEDIA] [-e], where

<i>[IP: Web-SSLPort]</i>	<i>IP Address: Port Number</i>
<i>IPv4</i>	<i>IPv4 format address e.g.: 10.0.6.8:443</i>
<i>IPv6</i>	<i>IPv6 format address e.g.: [2004::2000]:443</i>
<i>Web-SSLPort</i>	<i>IP should be given with in Ankle bracket like [2004::2000] for IPV6 HTTPS port number</i>
<i>[RAC- USER]</i>	<i>User Name User id, with 'virtual media' privilege Password</i>
<i>[RAC- PASSWORD]</i>	<i>User password, with 'virtual media' privilege</i>

[MEDIA TYPE]

- c CD/DVD Drive and CD/DVD Image Floppy
- f Drive and Floppy Image
- hd Hard Disk Drive, Hard Disk Image and USB

[MEDIA] Media drive (or) Media Image

- Media Drive Device name like /dev/sda, /dev/sdb

NOTE

Device name should not include partition name like /dev/sda1, /dev/sda2. Avoid partition name.

- [-e] Enable encrypted data transfer through ssl.

8. Stop the service.

```
root@sengud-vpn:/home/gopi/linux_x86_32
[root@sengud-vpn Linux_x86_32]# service vmcli start
Starting the VMCLI Service
[root@sengud-vpn Linux_x86_32]# service vmcli stop
Stopping the VMCLI Service
[root@sengud-vpn Linux_x86_32]#
```

The above VMCLI Screen 2 starts VMCLI service without command line argument i.e., configuration will be read from conf file.

Examples of Floppy Media redirection

Eg1:

IPv4: service vmcli start -r 10.0.6.8:443 -u admin -p admin -f /dev/sdb

IPv6: service vmcli start -r [2004::2000] :443 -u admin -p admin -f /dev/sdb

Description: This command is to redirect the floppy drive from the management station to the host.

Eg2: IPv4 : service vmcli start -r 10.0.6.8:443 -u admin -p admin -f /dev/sdb -e

IPv6: service vmcli start -r [2004::2000] :443 -u admin -p admin -f /dev/sdb -e

Description: This command is to redirect the floppy drive from the management station to the host. Data will be transfer through ssl.

Eg3:

IPv4: service vmcli start -r 10.0.6.8:443 -u admin -p admin -f "/home/fd.img"

IPv6: service vmcli start -r [2004::2000] :443 -u admin -p admin -f "/home/fd.img"

Description: This command is to redirect the floppy image from the management station to the host. The image file path is full system path.

Eg4: service vmcli stop

Description: This command is used to stop the vmcli service to stop the redirection.

Examples of CD-ROM Media redirection

Eg1:

IPv4: service vmcli start -r 10.0.6.8:443 -u admin -p admin -c /dev/sdc

IPv6: service vmcli start -r [2004::2000] :443 -u admin -p admin -c /dev/sdc

Description: This command is to redirect the CD/DVD drive from the management station to the host.

Eg2: IPv4 : service vmcli start -r 10.0.6.8:443 -u admin -p admin -c "/home/cdrom.iso"

IPv6: service vmcli start -r [2004::2000] :443 -u admin -p admin -c "/home/cdrom.iso"

Description: This command is to redirect the floppy image from the management station to the host. The image file path is full system path.

Eg3:

IPv4: service vmcli start -r 10.0.6.8 :443 -u admin -p admin -c CD-RomImage.iso -e

IPv6: service vmcli start -r [2004::2000] :443 -u admin -p admin -c CD-RomImage.iso -e

Description: This command is to redirect the CD/DVD image from the management station to the host. Data will be transfer through ssl.

Eg4: service vmcli stop

Description: This command is used to stop the vmcli service to stop the redirection.

Examples of Hard Disk Drive Media redirection

Eg1:

IPv4: service vmcli start -r 10.0.6.8:443 -u admin -p admin -hd /dev/sda

IPv6: service vmcli start -r [2004::2000] :443 -u admin -p admin -hd /dev/sda

Description: This command is to redirect the Hard disk drive from the management station to the host

Eg2:

IPv4: service vmcli start -r 10.0.6.8:443 -u admin -p admin -hd "/home/hd.img"

IPv6: service vmcli start -r [2004::2000] :443 -u admin -p admin -hd "/home/hd.img"

Description: This command is to redirect the floppy image from the management station to the host. The image file path is full system path.

Eg3:

IPv4: service vmcli start -r 10.0.6.8 :443 -u admin -p admin -hd /dev/sda -e

IPv6: service vmcli start -r [2004::2000] :443 -u admin -p admin -hd /dev/sda -e

Description: This command is to redirect the Hard disk drive from the management station to the host. Data will be transfer through ssl.

Eg4: service vmcli stop

Description: This command is used to stop the vmcli service to stop the redirection.

Configuration File Support

VMCLI supports the configuration file to pass the argument to the VMCLI service. The VMCLI service will read the configurations from the file, if the VMCLI service is started with no command line argument.

Eg: service vmcli start

[Linux] – filename is /etc/vmcli/vmcli.conf Sc start vmcli [Windows] – filename is C:\WINDOWS\vmcli.conf

Log file support is added to VMCLI service. The VMCLI service's start and stop information can be logged into this file (/var/log/vmcli or C:\WINDOWS\vmcli).

NOTE

VMCLI service will not be started if the command line arguments or configuration file are not configured properly.

```

root@sengud-vpn:/home/gopi/linux_x86_32
[root@sengud-vpn Linux_x86_32]# cat /etc/vmcli/vmcli.conf
[config]
ipaddr=10.0.7.236
username=admin
password=admin
port=443
encryption=0
cdredirect=/home/cdimage.iso
fdredirect=
hdredirect=
[root@sengud-vpn Linux_x86_32]#

```

VMCLI OS Compatibility

VCLM	Windows Server 2008 SP2	RHEL5.4	RHEL6.0	SLES11	Ubuntu server 10.04
	Result	Result	Result	Result	Result
Floppy					
Image: VMCLI BMCIP::443 -u admin -p admin -f floppy.img	Pass	Pass	Pass	Pass	Pass
Drive: VMCLI -r BMCIP::443 -u admin -p admin -f FDDrive	Pass	Pass	Pass	Pass	Pass
CDROM					
Image: VMCLI -r BMCIP::443 -u admin -p admin -c CD.iso	Pass	Pass	Pass	Pass	Pass
Drive: VMCLI -r BMCIP::443 -u admin -p admin -c CDDrive:\	Pass	Pass	Pass	Pass	Pass
Hard Disk					
Image: VMCLI -r BMCIP::443 -u admin -p admin -hd USB.img	Pass	Pass	Pass	Pass	Pass
Drive: VMCLI -r BMCIP::443 -u admin -p admin -hd HDDrive:\	Pass	Pass	Pass	Pass	Pass

Chapter 14. SOL

One of the powerful tools in IPMI is Serial Over LAN (SOL) which provides serial line access over the management LAN. The baseboard management controller (BMC) microcontroller embedded on the server motherboard does this by redirecting information destined for the serial port over to the LAN. With SOL console redirection system administrators can remotely view the text-based console on their remote servers from anywhere and perform any task that doesn't require a GUI.

Transporting serial data over IP networks using telnet, serial over IP, SOL and the likes is the way forward for server serial communications. Just as the KVM functions in embedded service processors is displacing the need for external KVM appliances, so the SOL capability of BMCs and console redirection in service processors is reducing the need for serial console servers for server console management.

Chapter 15. Technical Support



www.aicipc.com

Taiwan, Global Headquarters

Address: No. 152, Section 4,
Linghang N. Rd, Dayuan District,
Taoyuan City 337, Taiwan
Tel: +886-3-433-9188
Fax: +886-3-287-1818
Sales Email: sales@aicipc.com.tw
Support Email: support@aicipc.com

Shanghai, China

Address: Room 215, Building 4, No.471
Guiping Road, Xuhui District, Shanghai City,
200233 China
Tel: +86-21-54961421
Sales Email: sales@aicipc.com.cn
Support Email: support@aicipc.com

Moscow, Russia

Address: No.500, 5th Floor, 5th Entrance,
32A, Khoroshevskoye Shosse, Moscow,
123007
Tel: +7-4997019998
Sales Email: support-ru@aicipc.com.tw
Support Email: rma.russia@aicipc.com.tw

North California, United States

Address: 48531 Warm Springs
Boulevard Suite 404 Fremont, CA
94539, United States
Tel: +1-510-573-6730
Sales Email: sales@aicipc.com
Support Email: support@aicipc.com

South California, United States

Address: 21808 Garcia Lane
City of Industry, CA 91789,
United States
Toll free: + 1-866-800-0056
Tel: +1-909-895-8989
Fax: +1-909-895-8999
Sales Email: sales@aicipc.com
Support Email: support@aicipc.com

New Jersey, United States

Address: 322 Route 46 West Suite 100
Parsippany, NJ 07054 United States
Tel: +1-973-884-8886
Fax: +1-973-884-4794
Sales Email: sales@aicipc.com
Support Email: support@aicipc.com

Houten, The Netherlands

Address: Peppelkade 58, 3992AK, Houten,
The Netherlands
Tel: +31-30-6386789
Fax: +31-30-6360638
Sales Email: sales@aicipc.nl
Support Email: support@aicipc.com

Appendix

Ports Usage

Port #	Owner Module	Usage
80	Web server(webgo/ lighttpd)	Listening for network connections on HTTP://
443	Web server(webgo/ lighttpd)	Listening for secured network connections on HTTPS://
23	Telnet	Telnet session
5120	CD media server	To accept regular CD media redirection connections
5124	CD media server	To accept secure (SSL based) CD media redirection connections
5123	HDmedia server	To accept regular HD media redirection connections
5127	HDmedia server	To accept secure (SSL based) HD media redirection connections
7578	KVM server (adviser)	To accept regular KVM redirection connections
7582	KVM server (adviser)	To accept secure (SSL based) KVM redirection connections
623	IPMI	LAN interface
1900	uPnP discovery	Used for uPnP based BMC discovery
50000	uPnP discovery	Used for uPnP based BMC discovery
427	SLPD	Service Locator
123	NTP	Network Time Protocol (NTP) - used for time synchronization (UDP Connection)
161	SNMP	SNMP listens on this port for incoming SNMP requests. (UDP)
199	SNMP	SNMP listens on this port for incoming connect requests (from the SMUX peers and various other TCP end-points connected to SMUX peers to exchange SMUX PDUs)
546	DHCPv6	DHCPv6 clients listen for DHCP messages on this port (UDP)

Mouse Mode

Host OS	Mouse Mode
Windows Server 2016 Standard (exclude Nano Server)	Absolute
Windows Server 2012 R2	Absolute
RSLES Server 12.1	Absolute
SLES Server 11.4	Absolute
RHEL 7.3	Absolute
Ubuntu Server 16.04	Absolute
Ubuntu Server 14.04	Absolute

NOTE

AMI MegaRAC® SP-X suggests users to use Linux version of OS except SUSE 11.4 with BMC to avoid mouse sync issue in absolute mouse mode. Client cursor will be hidden always. If you want to enable, use Alt + C to access the menu.

KVM Sharing Scenario

KVM Client	KVM	Vmedia(Jviewer)	VMCLI
Client 1 (Full Privilege)	Connected	Allowed	Allowed
Client 2 (Partial Privilege)	Connected	Not Allowed	Not Allowed

VMedia Sharing Scenario**NOTE**

If MULTIPLE_USER_VMEDIA feature is disabled, then only one VMedia client can redirect media at a time. In the following table, KVM represents the video and JViewer/H5Viewer represents the media redirection from the JViewer/H5Viewer client.

Scenario 1:

KVM Client	KVM	JViewer/ H5Viewer Media	VMapp	VMCLI
Client 1	Connected	Connected	Not Allowed	Not Allowed
Client 2 (Partial Privilege)	Connected	Not Allowed		

Scenario 2:

KVM Client	KVM	JViewer/ H5Viewer Media	VMapp	VMCLI
Client 1 (Partial Privilege)	Connected	Not Allowed	Not Allowed	Not Allowed
Client 2 (Partial Privilege)	Connected	Connected		

Scenario 3:

KVM Client	KVM	JViewer/ H5Viewer Media	VMapp	VMCLI
Client 1 (Partial Privilege)	Connected	Not Allowed	Connected	Not Allowed
Client 2 (Partial Privilege)	Connected	Not Allowed		

Scenario 4:

KVM Client	KVM	JViewer/ H5Viewer Media	VMapp	VMCLI
Client 1 (Partial Privilege)	Connected	Not Allowed	Not Allowed	Connected
Client 2 (Partial Privilege)	Connected	Not Allowed		

Default IPMI Channel Numbers

Interface	Channel Number
Primary LAN Channel	0x01
Secondary LAN Channel	0x08
Serial Channel	0x02
Primary IPMB Channel	0x00
Secondary IPMB Channel	0x06
Third IPMB Channel	0x0a
System Interface	0x0f
SMM Interface	0x05

Secured Communication

- AD, LDAP, RADIUS based user authentication support
- Local IPMI user based authentication support
- Role/Privilege based authentication for each user for extra security
- Encrypted password support for AD/LDAP server authentication
- Single port access support for web/KVM/vMedia for enhanced security
- IPMI – Cipher suites support
- System Firewall support for IP/port level or IP/port range based blocking
- IPMI command/sub-command level firewall support
- TSIG authentication support for DNS controlled/secured access to the server
- SMTP-AUTH support
- OpenSSL based encryption – Latest OpenSSL 1.0.1 supported
- Key based Feature licensing/access support
- Secured handshaking support across concurrent KVM client sessions for

Service Listings

Service	User Authentication	Encryption
Web	Yes	Openssl
KVM	Yes	Openssl
vMedia	Yes	Openssl
Standalone KVM Client	Yes	Openssl
Standalone vMedia client	Yes	Openssl
SSL based SOL	Yes	Openssl
SNMP (v3)	Yes	SHA,MD5,AES,DES
SSH	Yes	Openssl
IPMI	Yes	Please refer list of supported cipher suites
YAFUFLASH (Out of band)	Yes	Please refer list of supported cipher suites
Standalone vMedia client	Yes	Openssl
SSL based SOL	Yes	Openssl
SNMP (v3)	Yes	SHA,MD5,AES,DES
SSH	Yes	Openssl
IPMI	Yes	Please refer list of supported cipher suites
YAFUFLASH (Out of band)	Yes	Please refer list of supported cipher suites

List of supported cipher suites in IPMI

ID	Authentication Algorithm	Integrity Algorithm	Confidentiality Algorithm
0	RAKP – NONE	NONE	NONE
1	RAKP-HMAC- SHA1	NONE	NONE
2	RAKP-HMAC- SHA1	HMAC-SHA1-96	NONE
3	RAKP-HMAC- SHA1	HMAC-SHA1-96	AES-CBC-128
6	RAKP-HMAC- MD5	NONE	NONE
7	RAKP-HMAC- MD5	HMAC-MD5-128	NONE
8	RAKP-HMAC- MD5	HMAC-MD5-128	AES-CBC-128
11	RAKP-HMAC- MD5	MD5-128	NONE
12	RAKP-HMAC- MD5	MD5-128	AES-CBC-128
15	RAKP_HMAC_ SHA256	NONE	NONE
16	RAKP_HMAC_ SHA256	HMAC-SHA256-128	NONE
17	RAKP_HMAC_ SHA256	HMAC-SHA256-128	AES-CBC-128