

Universal IO Shield for 1U



Step 1: install I/O bracket and put m/b on back.



Step 2: marked the connector's hole





Step 3: cutting the grill.

Step 4: reinstall I/O bracket and M/B---- finish.

